



# Depth of Field Tables in feet

for

## Compact Prime CP.2 Super Speed Lenses

for

	MFT format	ANSI Super 35, Normal 35, APS-H and APS-C Format	Full Format
CP.2 35 mm/T1.5 Super Speed	■	■	■
CP.2 50 mm/T1.5 Super Speed	■	■	■
CP.2 85 mm/T1.5 Super Speed	■	■	■

Depth of field tables

**Compact Prime CP.2 35mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	1.5		2		2.8	
feet	from	to	from	to	from	to
INF	159' 2 1/2"	INF	147' 3"	INF	120' 2 1/4"	INF
40'	32' 3/4"	53' 9 3/4"	31' 6 3/4"	68' 5 1/2"	30' 1 3/4"	114' 2 1/4"
20'	17' 10"	22' 10 3/4"	17' 8 1/4"	25' 1 1/2"	17' 2 3/4"	29' 4 1/2"
10'	9' 5 1/4"	10' 7 3/4"	9' 4 3/4"	11' 1"	9' 3 1/4"	11' 9 3/4"
8'	7' 7 3/4"	8' 4 3/4"	7' 7 1/2"	8' 8"	7' 6 1/2"	9' 1 1/4"
6'	5' 9 3/4"	6' 2 1/2"	5' 9 1/2"	6' 4 1/4"	5' 9"	6' 7"
5'	4' 10 1/2"	5' 1 3/4"	4' 10 1/4"	5' 2 3/4"	4' 10"	5' 4 1/2"
4' 6"	4' 4 3/4"	4' 7 1/2"	4' 4 3/4"	4' 8 1/4"	4' 4 1/4"	4' 9 3/4"
4'	3' 11"	4' 1"	3' 11"	4' 1 3/4"	3' 10 3/4"	4' 2 3/4"
3' 6"	3' 5 1/4"	3' 6 3/4"	3' 5 1/4"	3' 7 1/4"	3' 5"	3' 8"
3'	2' 11 1/2"	3' 1/2"	2' 11 1/2"	3' 1"	2' 11 1/4"	3' 1 1/2"
2' 9"	2' 8 1/2"	2' 9 1/2"	2' 8 1/2"	2' 9 3/4"	2' 8 1/2"	2' 10 1/4"
2' 6"	2' 5 3/4"	2' 6 1/4"	2' 5 3/4"	2' 6 1/2"	2' 5 1/2"	2' 7"
2' 3"	2' 2 3/4"	2' 3 1/4"	2' 2 3/4"	2' 3 1/2"	2' 2 3/4"	2' 3 3/4"
2'	1' 11 3/4"	2' 1/4"	1' 11 3/4"	2' 1/4"	1' 11 3/4"	2' 1/2"
1' 11"	1' 10 3/4"	1' 11 1/4"	1' 10 3/4"	1' 11 1/4"	1' 10 3/4"	1' 11 1/2"
1' 10"	1' 9 3/4"	1' 10 1/4"	1' 9 3/4"	1' 10 1/4"	1' 9 3/4"	1' 10 1/2"
1' 9"	1' 8 3/4"	1' 9 1/4"	1' 8 3/4"	1' 9 1/4"	1' 8 3/4"	1' 9 1/2"
1' 8"	1' 7 3/4"	1' 8 1/4"	1' 7 3/4"	1' 8 1/4"	1' 7 3/4"	1' 8 1/4"
1' 7"	1' 7"	1' 7"	1' 7"	1' 7 1/4"	1' 6 3/4"	1' 7 1/4"
1' 6"	1' 6"	1' 6"	1' 6"	1' 6 1/4"	1' 5 3/4"	1' 6 1/4"
1' 5"	1' 5"	1' 5"	1' 5"	1' 5 1/4"	1' 5"	1' 5 1/4"
1' 4"	1' 4"	1' 4"	1' 4"	1' 4"	1' 4"	1' 4 1/4"
1' 3"	1' 3"	1' 3"	1' 3"	1' 3"	1' 3"	1' 3 1/4"
1' 2"	1' 2"	1' 2"	1' 2"	1' 2"	1' 2"	1' 2 1/4"
1' 1"	1' 1"	1' 1"	1' 1"	1' 1"	1' 1"	1' 1"
1'	1'	1'	1'	1'	1'	1'

Depth of field tables

**Compact Prime CP.2 35mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	88' 7 3/4"	INF	58' 10 1/2"	INF	37' 11 3/4"	INF
40'	27' 8 1/2"	752' 7 1/2"	23' 11 3/4"	INF	19' 7 3/4"	INF
20'	16' 5"	37' 4 1/2"	15' 3/4"	55' 8 3/4"	13' 3"	147' 11 1/4"
10'	9' 1/2"	12' 10 3/4"	8' 7 1/2"	14' 5 3/4"	8' 1/4"	17' 1 3/4"
8'	7' 4 3/4"	9' 8 1/2"	7' 1 1/4"	10' 6 3/4"	6' 8 1/2"	11' 10 3/4"
6'	5' 8"	6' 10 1/2"	5' 6"	7' 3 1/2"	5' 3 1/4"	7' 10 1/2"
5'	4' 9 1/4"	5' 7"	4' 7 3/4"	5' 10"	4' 5 3/4"	6' 2 1/4"
4' 6"	4' 3 3/4"	4' 11 1/2"	4' 2 3/4"	5' 1 3/4"	4' 1"	5' 5"
4'	3' 10 1/4"	4' 4 1/4"	3' 9 1/2"	4' 6"	3' 8"	4' 8 1/4"
3' 6"	3' 4 3/4"	3' 9"	3' 4"	3' 10 1/4"	3' 3"	4'
3'	2' 11"	3' 2 1/4"	2' 10 1/2"	3' 3"	2' 10"	3' 4 1/4"
2' 9"	2' 8 1/4"	2' 10 3/4"	2' 7 3/4"	2' 11 1/2"	2' 7 1/4"	3' 1/2"
2' 6"	2' 5 1/2"	2' 7 1/2"	2' 5"	2' 8"	2' 4 1/2"	2' 8 3/4"
2' 3"	2' 2 1/2"	2' 4"	2' 2 1/4"	2' 4 1/2"	2' 2"	2' 5"
2'	1' 11 3/4"	2' 3/4"	1' 11 1/2"	2' 1"	1' 11 1/4"	2' 1 1/2"
1' 11"	1' 10 3/4"	1' 11 3/4"	1' 10 1/2"	2'	1' 10 1/4"	2' 1/2"
1' 10"	1' 9 3/4"	1' 10 3/4"	1' 9 1/2"	1' 11"	1' 9 1/4"	1' 11 1/4"
1' 9"	1' 8 3/4"	1' 9 1/2"	1' 8 1/2"	1' 9 3/4"	1' 8 1/2"	1' 10"
1' 8"	1' 7 3/4"	1' 8 1/2"	1' 7 3/4"	1' 8 3/4"	1' 7 1/2"	1' 9"
1' 7"	1' 6 3/4"	1' 7 1/2"	1' 6 3/4"	1' 7 1/2"	1' 6 1/2"	1' 7 3/4"
1' 6"	1' 5 3/4"	1' 6 1/2"	1' 5 3/4"	1' 6 1/2"	1' 5 1/2"	1' 6 3/4"
1' 5"	1' 4 3/4"	1' 5 1/4"	1' 4 3/4"	1' 5 1/2"	1' 4 3/4"	1' 5 1/2"
1' 4"	1' 3 3/4"	1' 4 1/4"	1' 3 3/4"	1' 4 1/2"	1' 3 3/4"	1' 4 1/2"
1' 3"	1' 3"	1' 3 1/4"	1' 2 3/4"	1' 3 1/4"	1' 2 3/4"	1' 3 1/2"
1' 2"	1' 2"	1' 2 1/4"	1' 1 3/4"	1' 2 1/4"	1' 1 3/4"	1' 2 1/4"
1' 1"	1' 1"	1' 1 1/4"	1' 1"	1' 1 1/4"	1' 3/4"	1' 1 1/4"
1'	1'	1'	1'	1' 1/4"	11 3/4"	1' 1/4"

Depth of field tables

**Compact Prime CP.2 35mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	24' 10 1/4"	INF	16' 7 3/4"	INF	11' 4 3/4"	INF
40'	15' 6"	INF	11' 10 3/4"	INF	8' 11 3/4"	INF
20'	11' 3"	INF	9' 3"	INF	7' 5"	INF
10'	7' 3 1/4"	22' 10 1/2"	6' 5"	43'	5' 6"	INF
8'	6' 2 1/4"	14' 4"	5' 6 3/4"	20' 1 1/2"	4' 10 1/2"	47' 8 3/4"
6'	4' 11 1/4"	8' 10"	4' 6 1/2"	10' 8"	4' 1"	15' 2 1/4"
5'	4' 3"	6' 9 1/4"	3' 11 1/2"	7' 9"	3' 7 1/2"	9' 10"
4' 6"	3' 10 3/4"	5' 10 1/4"	3' 8"	6' 6 3/4"	3' 4 1/2"	7' 11 1/2"
4'	3' 6 1/4"	5'	3' 4"	5' 6"	3' 1"	6' 5 1/4"
3' 6"	3' 1 3/4"	4' 2 3/4"	2' 11 3/4"	4' 6 3/4"	2' 9 1/2"	5' 2"
3'	2' 9"	3' 6"	2' 7 1/2"	3' 8 1/2"	2' 5 3/4"	4' 1"
2' 9"	2' 6 1/2"	3' 1 3/4"	2' 5 1/4"	3' 3 3/4"	2' 3 3/4"	3' 7 1/4"
2' 6"	2' 4"	2' 9 3/4"	2' 3"	2' 11 1/4"	2' 1 3/4"	3' 2"
2' 3"	2' 1 1/4"	2' 5 3/4"	2' 1/2"	2' 7"	1' 11 3/4"	2' 9"
2'	1' 10 3/4"	2' 2"	1' 10 1/4"	2' 3"	1' 9 1/2"	2' 4 1/4"
1' 11"	1' 9 3/4"	2' 1"	1' 9 1/4"	2' 1 3/4"	1' 8 3/4"	2' 2 3/4"
1' 10"	1' 9"	1' 11 3/4"	1' 8 1/2"	2' 1/2"	1' 8"	2' 1 1/2"
1' 9"	1' 8"	1' 10 1/2"	1' 7 3/4"	1' 11"	1' 7"	2'
1' 8"	1' 7 1/4"	1' 9 1/4"	1' 6 3/4"	1' 9 3/4"	1' 6 1/4"	1' 10 3/4"
1' 7"	1' 6 1/4"	1' 8 1/4"	1' 6"	1' 8 1/2"	1' 5 1/2"	1' 9 1/4"
1' 6"	1' 5 1/2"	1' 7"	1' 5"	1' 7 1/2"	1' 4 3/4"	1' 8"
1' 5"	1' 4 1/2"	1' 5 3/4"	1' 4 1/4"	1' 6 1/4"	1' 4"	1' 6 3/4"
1' 4"	1' 3 1/2"	1' 4 3/4"	1' 3 1/4"	1' 5"	1' 3"	1' 5 1/2"
1' 3"	1' 2 1/2"	1' 3 1/2"	1' 2 1/2"	1' 3 3/4"	1' 2 1/4"	1' 4 1/4"
1' 2"	1' 1 3/4"	1' 2 1/2"	1' 1 1/2"	1' 2 3/4"	1' 1 1/4"	1' 3"
1' 1"	1' 3/4"	1' 1 1/2"	1' 3/4"	1' 1 1/2"	1' 1/2"	1' 1 3/4"
1'	11 3/4"	1' 1/4"	11 3/4"	1' 1/2"	11 1/2"	1' 1/2"



Depth of field tables

**Compact Prime CP.2 50mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	925' 3 3/4"	INF	407' 1 1/4"	INF	159' 9 3/4"	INF
50'	47' 5"	219' 9"	44' 6 1/4"	INF	38' 1 1/2"	INF
30'	29' 1/2"	55' 6 3/4"	27' 11 1/4"	80' 8 1/4"	25' 3 1/2"	157' 10 1/2"
20'	19' 6 3/4"	28' 8 3/4"	19' 3/4"	34' 2 1/4"	17' 9 3/4"	43' 1/4"
15'	14' 9"	19' 4 1/2"	14' 5 1/2"	21' 8 1/4"	13' 8 3/4"	24' 10 3/4"
12'	11' 10"	14' 7 1/2"	11' 8"	15' 10 1/2"	11' 2 1/4"	17' 6 1/4"
10'	9' 10 3/4"	11' 8 3/4"	9' 9"	12' 6 1/4"	9' 5"	13' 6 1/4"
9'	8' 11"	10' 4 1/2"	8' 9 3/4"	10' 11 3/4"	8' 6 1/2"	11' 8 3/4"
8'	7' 11 1/4"	9' 3/4"	7' 10 1/4"	9' 6 1/4"	7' 7 1/2"	10' 3/4"
7'	6' 11 1/4"	7' 9 1/2"	6' 10 1/2"	8' 1 1/2"	6' 8 1/2"	8' 6 1/4"
6' 6"	6' 5 1/2"	7' 2"	6' 4 3/4"	7' 5 1/4"	6' 3"	7' 9 1/4"
6'	5' 11 1/2"	6' 6 3/4"	5' 11"	6' 9 1/2"	5' 9 1/2"	7' 3/4"
5' 6"	5' 5 1/2"	5' 11 1/2"	5' 5"	6' 1 3/4"	5' 4"	6' 4 1/2"
5'	4' 11 3/4"	5' 4 1/2"	4' 11 1/4"	5' 6 1/4"	4' 10 1/4"	5' 8 1/2"
4' 9"	4' 8 3/4"	5' 1"	4' 8 1/4"	5' 2 1/2"	4' 7 1/2"	5' 4 1/2"
4' 6"	4' 5 3/4"	4' 9 1/2"	4' 5 1/2"	4' 11"	4' 4 1/2"	5' 1/2"
4' 3"	4' 2 3/4"	4' 6 1/4"	4' 2 1/2"	4' 7 1/2"	4' 1 3/4"	4' 8 3/4"
4'	3' 11 3/4"	4' 2 3/4"	3' 11 1/2"	4' 3 3/4"	3' 11"	4' 5"
3' 9"	3' 8 3/4"	3' 11 1/4"	3' 8 1/2"	4' 1/4"	3' 8"	4' 1 1/4"
3' 6"	3' 5 3/4"	3' 8"	3' 5 3/4"	3' 8 3/4"	3' 5 1/4"	3' 9 3/4"
3' 3"	3' 2 3/4"	3' 4 3/4"	3' 2 3/4"	3' 5 1/2"	3' 2 1/4"	3' 6 1/4"
3'	2' 11 3/4"	3' 1 1/2"	2' 11 3/4"	3' 2"	2' 11 1/2"	3' 2 1/2"
2' 9"	2' 9"	2' 10 1/4"	2' 8 3/4"	2' 10 3/4"	2' 8 1/2"	2' 11 1/4"
2' 6"	2' 6"	2' 7"	2' 5 3/4"	2' 7 1/4"	2' 5 1/2"	2' 7 3/4"
2' 3"	2' 3"	2' 3 3/4"	2' 2 3/4"	2' 4"	2' 2 3/4"	2' 4 1/4"
2'	2'	2' 1/2"	2'	2' 3/4"	1' 11 3/4"	2' 1"
1' 11"	1' 11"	1' 11 1/2"	1' 11"	1' 11 3/4"	1' 10 3/4"	2'
1' 10"	1' 10"	1' 10 1/2"	1' 10"	1' 10 3/4"	1' 9 3/4"	1' 10 3/4"
1' 9"	1' 9"	1' 9 1/2"	1' 9"	1' 9 1/2"	1' 8 3/4"	1' 9 3/4"
1' 8"	1' 8"	1' 8 1/4"	1' 8"	1' 8 1/2"	1' 7 3/4"	1' 8 3/4"
1' 7"	1' 7"	1' 7 1/4"	1' 7"	1' 7 1/2"	1' 6 3/4"	1' 7 1/2"
1' 6"	1' 6"	1' 6 1/4"	1' 6"	1' 6 1/2"	1' 5 3/4"	1' 6 1/2"

Depth of field tables

**Compact Prime CP.2 50mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	79' 1 3/4"	INF	45' 2 1/4"	INF	28'	INF
50'	30' 8 3/4"	INF	23' 10"	INF	18' 3/4"	INF
30'	21' 10"	INF	18' 1 1/2"	INF	14' 7 1/4"	INF
20'	16' 1/4"	63' 5 3/4"	13' 11 1/2"	177' 5 1/2"	11' 9 1/4"	INF
15'	12' 8"	30' 6 3/4"	11' 4"	44' 3/4"	9' 10 1/2"	115' 4"
12'	10' 5 1/2"	20' 1 1/2"	9' 6 3/4"	25' 1 3/4"	8' 6"	38' 8 1/4"
10'	8' 11"	15'	8' 3"	17' 7 1/4"	7' 5 1/2"	23' 3"
9'	8' 1 1/2"	12' 9 3/4"	7' 6 3/4"	14' 8"	6' 10 3/4"	18' 4 1/4"
8'	7' 3 1/2"	10' 10 1/4"	6' 10 1/4"	12' 1 1/2"	6' 3 1/2"	14' 6 1/2"
7'	6' 5 1/2"	9' 3/4"	6' 1 1/4"	9' 11 1/4"	5' 8"	11' 5 1/2"
6' 6"	6' 1/2"	8' 2 3/4"	5' 8 3/4"	8' 11 1/4"	5' 4 1/4"	10' 1 3/4"
6'	5' 7 1/4"	7' 5 1/4"	5' 4"	8'	5'	8' 11 1/2"
5' 6"	5' 2"	6' 8"	4' 11 1/4"	7' 1 1/4"	4' 8"	7' 10 1/4"
5'	4' 8 3/4"	5' 11 1/4"	4' 6 1/2"	6' 3 1/2"	4' 3 1/2"	6' 10 1/4"
4' 9"	4' 6"	5' 7"	4' 4"	5' 10 1/2"	4' 1 1/2"	6' 4 1/2"
4' 6"	4' 3 1/4"	5' 2 3/4"	4' 1 1/2"	5' 6"	3' 11 1/4"	5' 11"
4' 3"	4' 1/2"	4' 10 3/4"	3' 11"	5' 1 1/2"	3' 9"	5' 5 3/4"
4'	3' 10"	4' 6 3/4"	3' 8 1/2"	4' 9"	3' 6 1/2"	5' 3/4"
3' 9"	3' 7 1/4"	4' 2 3/4"	3' 6"	4' 4 3/4"	3' 4 1/4"	4' 7 3/4"
3' 6"	3' 4 1/2"	3' 11"	3' 3 1/4"	4' 1/2"	3' 1 3/4"	4' 3 1/4"
3' 3"	3' 1 3/4"	3' 7 1/4"	3' 3/4"	3' 8 1/2"	2' 11 1/2"	3' 10 3/4"
3'	2' 10 3/4"	3' 3 1/2"	2' 10"	3' 4 1/2"	2' 9"	3' 6 1/4"
2' 9"	2' 8"	2' 11 3/4"	2' 7 1/2"	3' 3/4"	2' 6 1/2"	3' 2"
2' 6"	2' 5 1/4"	2' 8 1/4"	2' 4 3/4"	2' 9"	2' 4"	2' 10"
2' 3"	2' 2 1/2"	2' 4 3/4"	2' 2"	2' 5 1/4"	2' 1 1/4"	2' 6 1/4"
2'	1' 11 1/2"	2' 1 1/4"	1' 11 1/4"	2' 1 3/4"	1' 10 3/4"	2' 2 1/4"
1' 11"	1' 10 1/2"	2' 1/4"	1' 10 1/4"	2' 1/2"	1' 9 3/4"	2' 1"
1' 10"	1' 9 1/2"	1' 11"	1' 9 1/4"	1' 11 1/2"	1' 9"	2'
1' 9"	1' 8 3/4"	1' 10"	1' 8 1/2"	1' 10 1/4"	1' 8"	1' 10 3/4"
1' 8"	1' 7 3/4"	1' 8 3/4"	1' 7 1/2"	1' 9"	1' 7 1/4"	1' 9 1/2"
1' 7"	1' 6 3/4"	1' 7 3/4"	1' 6 1/2"	1' 8"	1' 6 1/4"	1' 8 1/4"
1' 6"	1' 5 3/4"	1' 6 3/4"	1' 5 1/2"	1' 6 3/4"	1' 5 1/4"	1' 7 1/4"

Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	1.5		2		2.8	
feet	from	to	from	to	from	to
<b>INF</b>	867' 2 3/4"	INF	379' 8 1/4"	INF	357' 9"	INF
<b>200'</b>	162' 7 1/4"	259' 9 3/4"	131' 2"	221' 8 1/4"	128' 5 1/4"	300' 2 1/2"
<b>100'</b>	89' 8 1/2"	112' 11 3/4"	79' 3 1/4"	105' 1 3/4"	78' 3 1/4"	119' 11 3/4"
<b>60'</b>	56' 1 3/4"	64' 5"	51' 10 3/4"	61' 9 3/4"	51' 5 1/2"	66' 7 1/2"
<b>40'</b>	38' 3"	41' 11"	36' 3"	40' 9 1/2"	36' 1/2"	42' 10"
<b>30'</b>	29' 1/4"	31' 3/4"	27' 10 1/4"	30' 5 1/2"	27' 8 3/4"	31' 6 3/4"
<b>25'</b>	24' 3 3/4"	25' 8 3/4"	23' 6"	25' 3 3/4"	23' 5"	26' 3/4"
<b>20'</b>	19' 6 3/4"	20' 5 1/2"	19' 1/2"	20' 2 1/2"	18' 11 3/4"	20' 8"
<b>17'</b>	16' 8 1/4"	17' 4"	16' 3 3/4"	17' 1 3/4"	16' 3"	17' 5 3/4"
<b>15'</b>	14' 9"	15' 3"	14' 5 1/2"	15' 1 1/4"	14' 5"	15' 4 1/2"
<b>14'</b>	13' 9 1/2"	14' 2 3/4"	13' 6 1/4"	14' 1 1/4"	13' 6"	14' 4"
<b>13'</b>	12' 9 3/4"	13' 2 1/4"	12' 7 1/4"	13' 1"	12' 6 3/4"	13' 3 1/4"
<b>12'</b>	11' 10"	12' 2"	11' 7 3/4"	12' 3/4"	11' 7 1/2"	12' 2 3/4"
<b>11'</b>	10' 10 1/2"	11' 1 1/2"	10' 8 1/2"	11' 3/4"	10' 8 1/4"	11' 2 1/4"
<b>10'</b>	9' 10 3/4"	10' 1 1/4"	9' 9 1/4"	10' 1/2"	9' 9"	10' 2"
<b>9' 6"</b>	9' 4 3/4"	9' 7 1/4"	9' 3 1/2"	9' 6 1/2"	9' 3 1/4"	9' 7 3/4"
<b>9'</b>	8' 11"	9' 1"	8' 9 3/4"	9' 1/2"	8' 9 1/2"	9' 1 1/2"
<b>8' 6"</b>	8' 5"	8' 7"	8' 4"	8' 6 1/2"	8' 3 3/4"	8' 7 1/2"
<b>8'</b>	7' 11 1/4"	8' 3/4"	7' 10 1/4"	8' 1/2"	7' 10"	8' 1 1/4"
<b>7' 9"</b>	7' 8 1/4"	7' 9 3/4"	7' 7 1/4"	7' 9 1/4"	7' 7 1/4"	7' 10 1/4"
<b>7' 6"</b>	7' 5 1/4"	7' 6 3/4"	7' 4 1/2"	7' 6 1/4"	7' 4 1/4"	7' 7"
<b>7' 3"</b>	7' 2 1/4"	7' 3 3/4"	7' 1 1/2"	7' 3 1/4"	7' 1 1/2"	7' 4"
<b>7'</b>	6' 11 1/4"	7' 3/4"	6' 10 3/4"	7' 1/4"	6' 10 1/2"	7' 1"
<b>6' 9"</b>	6' 8 1/2"	6' 9 1/2"	6' 7 3/4"	6' 9 1/4"	6' 7 3/4"	6' 9 3/4"
<b>6' 6"</b>	6' 5 1/2"	6' 6 1/2"	6' 4 3/4"	6' 6 1/4"	6' 4 3/4"	6' 6 3/4"
<b>6' 3"</b>	6' 2 1/2"	6' 3 1/2"	6' 2"	6' 3 1/4"	6' 1 3/4"	6' 3 3/4"
<b>6'</b>	5' 11 1/2"	6' 1/2"	5' 11"	6' 1/4"	5' 11"	6' 3/4"
<b>5' 9"</b>	5' 8 1/2"	5' 9 1/2"	5' 8"	5' 9 1/4"	5' 8"	5' 9 1/2"
<b>5' 6"</b>	5' 5 1/2"	5' 6 1/2"	5' 5 1/4"	5' 6 1/4"	5' 5 1/4"	5' 6 1/2"
<b>5' 3"</b>	5' 2 3/4"	5' 3 1/4"	5' 2 1/4"	5' 3 1/4"	5' 2 1/4"	5' 3 1/2"
<b>5'</b>	4' 11 3/4"	5' 1/4"	4' 11 1/4"	5' 1/4"	4' 11 1/4"	5' 1/2"
<b>4' 9"</b>	4' 8 3/4"	4' 9 1/4"	4' 8 1/2"	4' 9 1/4"	4' 8 1/4"	4' 9 1/2"
<b>4' 6"</b>	4' 5 3/4"	4' 6 1/4"	4' 5 1/2"	4' 6"	4' 5 1/2"	4' 6 1/4"
<b>4' 3"</b>	4' 2 3/4"	4' 3 1/4"	4' 2 1/2"	4' 3"	4' 2 1/2"	4' 3 1/4"
<b>4'</b>	3' 11 3/4"	4' 1/4"	3' 11 1/2"	4'	3' 11 1/2"	4' 1/4"
<b>3' 9"</b>	3' 8 3/4"	3' 9 1/4"	3' 8 3/4"	3' 9"	3' 8 1/2"	3' 9 1/4"
<b>3' 6"</b>	3' 5 3/4"	3' 6 1/4"	3' 5 3/4"	3' 6"	3' 5 3/4"	3' 6 1/4"
<b>3' 3"</b>	3' 3"	3' 3"	3' 2 3/4"	3' 3"	3' 2 3/4"	3' 3 1/4"



Depth of field tables

## Compact Prime CP.2 85mm/T1.5 Super Speed T\*

circle of confusion: 0.020 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	318' 10 1/2"	INF	246' 10 1/4"	INF	175' 6"	INF
200'	123' 3/4"	559' 10"	110' 7 1/2"	23369' 9"	93' 7 1/2"	INF
100'	76' 2 3/4"	147' 1 3/4"	71' 3 1/2"	197' 8"	63' 10"	337' 9"
60'	50' 7"	74' 2 1/2"	48' 4 1/4"	85' 1 1/2"	44' 10"	103' 6 1/2"
40'	35' 7 1/4"	45' 9 3/4"	34' 6"	49' 8 3/4"	32' 8"	55' 5 1/2"
30'	27' 5 3/4"	33' 1 3/4"	26' 9 3/4"	35' 1 1/2"	25' 8 1/4"	37' 10 1/2"
25'	23' 2 3/4"	27' 1 1/2"	22' 9"	28' 5 1/4"	21' 11 1/4"	30' 2 1/2"
20'	18' 10 1/4"	21' 4"	18' 6 1/2"	22' 1 1/2"	18'	23' 2"
17'	16' 2"	17' 11 1/4"	15' 11 1/4"	18' 6"	15' 6 1/2"	19' 2 3/4"
15'	14' 4 1/4"	15' 8 3/4"	14' 2"	16' 1 3/4"	13' 10 1/4"	16' 8 1/4"
14'	13' 5 1/4"	14' 7 1/2"	13' 3 1/4"	15'	13'	15' 5 1/2"
13'	12' 6 1/4"	13' 6 1/2"	12' 4 1/2"	13' 10 1/4"	12' 1 3/4"	14' 3"
12'	11' 7"	12' 5 1/2"	11' 5 3/4"	12' 8 1/2"	11' 3 1/4"	13' 1/2"
11'	10' 7 3/4"	11' 4 1/2"	10' 6 3/4"	11' 7 1/4"	10' 4 1/2"	11' 10 1/2"
10'	9' 8 1/2"	10' 3 3/4"	9' 7 1/2"	10' 5 3/4"	9' 6"	10' 8 1/2"
9' 6"	9' 3"	9' 9 1/4"	9' 2"	9' 11 1/4"	9' 1/2"	10' 1 1/2"
9'	8' 9 1/4"	9' 3"	8' 8 1/2"	9' 4 3/4"	8' 7"	9' 6 3/4"
8' 6"	8' 3 1/2"	8' 8 3/4"	8' 2 3/4"	8' 10 1/4"	8' 1 1/2"	9'
8'	7' 9 3/4"	8' 2 1/4"	7' 9 1/4"	8' 3 3/4"	7' 8"	8' 5 1/4"
7' 9"	7' 7"	7' 11 1/4"	7' 6 1/2"	8' 1/2"	7' 5 1/4"	8' 2"
7' 6"	7' 4"	7' 8"	7' 3 1/2"	7' 9 1/4"	7' 2 1/2"	7' 10 1/2"
7' 3"	7' 1 1/4"	7' 5"	7' 3/4"	7' 6"	6' 11 3/4"	7' 7 1/4"
7'	6' 10 1/4"	7' 1 3/4"	6' 10"	7' 2 3/4"	6' 9"	7' 4"
6' 9"	6' 7 1/2"	6' 10 3/4"	6' 7"	6' 11 1/2"	6' 6 1/4"	7' 3/4"
6' 6"	6' 4 1/2"	6' 7 1/2"	6' 4 1/4"	6' 8 1/4"	6' 3 1/2"	6' 9 1/4"
6' 3"	6' 1 3/4"	6' 4 1/2"	6' 1 1/4"	6' 5 1/4"	6' 3/4"	6' 6"
6'	5' 10 3/4"	6' 1 1/4"	5' 10 1/2"	6' 2"	5' 9 3/4"	6' 2 3/4"
5' 9"	5' 8"	5' 10 1/4"	5' 7 1/2"	5' 10 3/4"	5' 7"	5' 11 1/2"
5' 6"	5' 5"	5' 7"	5' 4 3/4"	5' 7 3/4"	5' 4 1/4"	5' 8 1/4"
5' 3"	5' 2"	5' 4"	5' 1 3/4"	5' 4 1/2"	5' 1 1/4"	5' 5"
5'	4' 11 1/4"	5' 3/4"	4' 11"	5' 1 1/4"	4' 10 1/2"	5' 2"
4' 9"	4' 8 1/4"	4' 9 3/4"	4' 8"	4' 10 1/4"	4' 7 3/4"	4' 10 3/4"
4' 6"	4' 5 1/4"	4' 6 3/4"	4' 5 1/4"	4' 7"	4' 4 3/4"	4' 7 1/2"
4' 3"	4' 2 1/2"	4' 3 1/2"	4' 2 1/4"	4' 4"	4' 2"	4' 4 1/4"
4'	3' 11 1/2"	4' 1/2"	3' 11 1/4"	4' 3/4"	3' 11"	4' 1 1/4"
3' 9"	3' 8 1/2"	3' 9 1/2"	3' 8 1/2"	3' 9 3/4"	3' 8 1/4"	3' 10"
3' 6"	3' 5 3/4"	3' 6 1/2"	3' 5 1/2"	3' 6 1/2"	3' 5 1/4"	3' 6 3/4"
3' 3"	3' 2 3/4"	3' 3 1/4"	3' 2 1/2"	3' 3 1/2"	3' 2 1/2"	3' 3 3/4"

Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.020 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	121' 6"	INF	83' 11 1/2"	INF	58' 3 3/4"	INF
200'	75' 8 3/4"	INF	59' 3 1/4"	INF	45' 3"	INF
100'	55'	4995' 10 1/4"	45' 9 1/2"	INF	36' 11 3/4"	INF
60'	40' 3 1/2"	144' 8 3/4"	35' 1 3/4"	320' 2 1/4"	29' 8 3/4"	INF
40'	30' 2 1/2"	65' 4 1/2"	27' 2 3/4"	86' 8 3/4"	23' 10 1/2"	160' 3 1/2"
30'	24' 1 3/4"	42' 2 3/4"	22' 2 3/4"	50' 2"	19' 11 1/4"	68' 1 3/4"
25'	20' 9 3/4"	32' 10 3/4"	19' 4 1/2"	37' 6"	17' 7 1/2"	46' 8 1/4"
20'	17' 3"	24' 8 1/2"	16' 3"	27' 2 1/2"	15'	31' 8 1/2"
17'	14' 11 3/4"	20' 3 1/4"	14' 2 3/4"	21' 10 3/4"	13' 3 1/4"	24' 8 1/2"
15'	13' 5"	17' 5 3/4"	12' 9 3/4"	18' 8"	12' 1/2"	20' 7 3/4"
14'	12' 7 1/4"	16' 1 1/2"	12' 1"	17' 1 1/2"	11' 4 3/4"	18' 9 1/2"
13'	11' 9 1/2"	14' 9 3/4"	11' 4"	15' 7 3/4"	10' 8 3/4"	17'
12'	10' 11 3/4"	13' 6 1/4"	10' 6 3/4"	14' 2 1/2"	10' 1/2"	15' 3 3/4"
11'	10' 1 1/2"	12' 3"	9' 9 1/2"	12' 9 3/4"	9' 4"	13' 8 1/2"
10'	9' 3 1/2"	11' 1/4"	9'	11' 5 1/2"	8' 7 1/4"	12' 2"
9' 6"	8' 10 1/4"	10' 5"	8' 7"	10' 9 3/4"	8' 3"	11' 5 1/4"
9'	8' 5"	9' 9 3/4"	8' 2 1/4"	10' 2"	7' 10 1/2"	10' 8 1/2"
8' 6"	7' 11 3/4"	9' 2 1/2"	7' 9 1/4"	9' 6 1/4"	7' 5 3/4"	10'
8'	7' 6 1/2"	8' 7 1/2"	7' 4 1/4"	8' 10 3/4"	7' 1 1/4"	9' 3 3/4"
7' 9"	7' 3 3/4"	8' 4"	7' 1 3/4"	8' 7"	6' 10 3/4"	8' 11 1/2"
7' 6"	7' 1 1/4"	8' 1/2"	6' 11 1/4"	8' 3 1/4"	6' 8 1/2"	8' 7 1/2"
7' 3"	6' 10 1/2"	7' 9"	6' 8 1/2"	7' 11 3/4"	6' 6"	8' 3 1/2"
7'	6' 7 3/4"	7' 5 1/2"	6' 6"	7' 8"	6' 3 3/4"	7' 11 1/2"
6' 9"	6' 5"	7' 2 1/4"	6' 3 1/2"	7' 4 1/2"	6' 1 1/4"	7' 7 3/4"
6' 6"	6' 2 1/2"	6' 10 3/4"	6' 1"	7' 3/4"	5' 10 3/4"	7' 3 3/4"
6' 3"	5' 11 3/4"	6' 7 1/2"	5' 10 1/4"	6' 9 1/4"	5' 8 1/2"	7'
6'	5' 9"	6' 4"	5' 7 3/4"	6' 5 3/4"	5' 6"	6' 8 1/4"
5' 9"	5' 6 1/4"	6' 3/4"	5' 5"	6' 2 1/4"	5' 3 1/2"	6' 4 1/2"
5' 6"	5' 3 1/2"	5' 9 1/4"	5' 2 1/4"	5' 10 3/4"	5' 1"	6' 3/4"
5' 3"	5' 3/4"	5' 6"	4' 11 3/4"	5' 7 1/4"	4' 10 1/4"	5' 9"
5'	4' 10"	5' 2 3/4"	4' 9"	5' 3 3/4"	4' 7 3/4"	5' 5 1/2"
4' 9"	4' 7"	4' 11 1/2"	4' 6 1/4"	5' 1/2"	4' 5 1/4"	5' 1 3/4"
4' 6"	4' 4 1/4"	4' 8"	4' 3 1/2"	4' 9"	4' 2 3/4"	4' 10 1/4"
4' 3"	4' 1 1/2"	4' 4 3/4"	4' 1"	4' 5 3/4"	4'	4' 6 3/4"
4'	3' 10 3/4"	4' 1 3/4"	3' 10 1/4"	4' 2 1/4"	3' 9 1/2"	4' 3 1/4"
3' 9"	3' 7 3/4"	3' 10 1/2"	3' 7 1/2"	3' 11"	3' 6 3/4"	3' 11 3/4"
3' 6"	3' 5"	3' 7 1/4"	3' 4 1/2"	3' 7 3/4"	3' 4"	3' 8 1/2"
3' 3"	3' 2 1/4"	3' 4"	3' 1 3/4"	3' 4 1/2"	3' 1 1/4"	3' 5"

Depth of field tables

**Compact Prime CP.2 35mm/T1.5 Super Speed T\***

circle of confusion: 0.025 mm

Engraving	T-Stop					
	1.5		2		2.8	
feet	from	to	from	to	from	to
INF	127' 1/4"	INF	111' 9 1/2"	INF	87' 9"	INF
40'	30' 6 1/2"	58' 10"	29' 7"	80' 3 1/2"	27' 7 1/2"	176' 3 1/2"
20'	17' 4 1/4"	23' 8 3/4"	17' 1/2"	26' 6 1/2"	16' 4 3/4"	32' 2 3/4"
10'	9' 3 3/4"	10' 10"	9' 2 3/4"	11' 4 1/4"	9' 1/2"	12' 3"
8'	7' 6 3/4"	8' 6"	7' 6"	8' 10"	7' 4 1/2"	9' 4"
6'	5' 9"	6' 3 1/4"	5' 8 3/4"	6' 5 1/4"	5' 7 3/4"	6' 8 1/2"
5'	4' 10"	5' 2 1/4"	4' 9 3/4"	5' 3 1/2"	4' 9 1/4"	5' 5 1/2"
4' 6"	4' 4 1/2"	4' 7 3/4"	4' 4 1/4"	4' 8 3/4"	4' 3 3/4"	4' 10 1/2"
4'	3' 10 3/4"	4' 1 1/4"	3' 10 1/2"	4' 2 1/4"	3' 10 1/4"	4' 3 1/4"
3' 6"	3' 5"	3' 7"	3' 5"	3' 7 1/2"	3' 4 3/4"	3' 8 1/2"
3'	2' 11 1/4"	3' 3/4"	2' 11 1/4"	3' 1"	2' 11"	3' 1 3/4"
2' 9"	2' 8 1/2"	2' 9 1/2"	2' 8 1/2"	2' 10"	2' 8 1/4"	2' 10 1/2"
2' 6"	2' 5 1/2"	2' 6 1/2"	2' 5 1/2"	2' 6 3/4"	2' 5 1/2"	2' 7"
2' 3"	2' 2 3/4"	2' 3 1/4"	2' 2 1/2"	2' 3 1/2"	2' 2 1/2"	2' 3 3/4"
2'	1' 11 3/4"	2' 1/4"	1' 11 3/4"	2' 1/2"	1' 11 3/4"	2' 3/4"
1' 11"	1' 10 3/4"	1' 11 1/4"	1' 10 3/4"	1' 11 1/2"	1' 10 3/4"	1' 11 1/2"
1' 10"	1' 9 3/4"	1' 10 1/4"	1' 9 3/4"	1' 10 1/4"	1' 9 3/4"	1' 10 1/2"
1' 9"	1' 8 3/4"	1' 9 1/4"	1' 8 3/4"	1' 9 1/4"	1' 8 3/4"	1' 9 1/2"
1' 8"	1' 7 3/4"	1' 8 1/4"	1' 7 3/4"	1' 8 1/4"	1' 7 3/4"	1' 8 1/2"
1' 7"	1' 6 3/4"	1' 7 1/4"	1' 6 3/4"	1' 7 1/4"	1' 6 3/4"	1' 7 1/4"
1' 6"	1' 5 3/4"	1' 6 1/4"	1' 5 3/4"	1' 6 1/4"	1' 5 3/4"	1' 6 1/4"
1' 5"	1' 5"	1' 5"	1' 5"	1' 5 1/4"	1' 4 3/4"	1' 5 1/4"
1' 4"	1' 4"	1' 4"	1' 4"	1' 4 1/4"	1' 3 3/4"	1' 4 1/4"
1' 3"	1' 3"	1' 3"	1' 3"	1' 3"	1' 3"	1' 3 1/4"
1' 2"	1' 2"	1' 2"	1' 2"	1' 2"	1' 2"	1' 2 1/4"
1' 1"	1' 1"	1' 1"	1' 1"	1' 1"	1' 1"	1' 1"
1'	1'	1'	1'	1'	1'	1'

Depth of field tables

## Compact Prime CP.2 35mm/T1.5 Super Speed T\*

circle of confusion: 0.025 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	63' 11 1/2"	INF	43' 2 3/4"	INF	28' 7 1/4"	INF
40'	24' 9 1/4"	INF	20' 11 1/4"	INF	16' 10 1/4"	INF
20'	15' 4 1/4"	44' 7 1/4"	13' 9 3/4"	85' 1"	11' 11 1/4"	INF
10'	8' 8 3/4"	13' 7 1/2"	8' 2 3/4"	15' 10"	7' 6 1/2"	20' 1"
8'	7' 2"	10' 1 1/4"	6' 10"	11' 3"	6' 4 1/2"	13' 2 1/2"
6'	5' 6 1/2"	7' 3/4"	5' 4"	7' 7 1/4"	5' 3/4"	8' 5"
5'	4' 8 1/4"	5' 8 1/2"	4' 6 1/2"	6' 1/4"	4' 4"	6' 6 1/4"
4' 6"	4' 3"	5' 1/2"	4' 1 1/2"	5' 3 1/2"	3' 11 1/2"	5' 8"
4'	3' 9 1/2"	4' 5"	3' 8 1/2"	4' 7 1/4"	3' 7"	4' 10 1/2"
3' 6"	3' 4 1/4"	3' 9 3/4"	3' 3 1/2"	3' 11 1/4"	3' 2 1/4"	4' 1 1/2"
3'	2' 10 3/4"	3' 2 1/2"	2' 10 1/4"	3' 3 3/4"	2' 9 1/4"	3' 5 1/4"
2' 9"	2' 8"	2' 11"	2' 7 1/2"	3'	2' 6 3/4"	3' 1 1/4"
2' 6"	2' 5 1/4"	2' 7 3/4"	2' 4 3/4"	2' 8 1/4"	2' 4 1/4"	2' 9 1/4"
2' 3"	2' 2 1/4"	2' 4 1/4"	2' 2"	2' 4 3/4"	2' 1 1/2"	2' 5 1/2"
2'	1' 11 1/2"	2' 1"	1' 11 1/4"	2' 1 1/4"	1' 11"	2' 2"
1' 11"	1' 10 1/2"	1' 11 3/4"	1' 10 1/4"	2' 1/4"	1' 10"	2' 3/4"
1' 10"	1' 9 1/2"	1' 10 3/4"	1' 9 1/2"	1' 11"	1' 9"	1' 11 1/2"
1' 9"	1' 8 3/4"	1' 9 3/4"	1' 8 1/2"	1' 10"	1' 8 1/4"	1' 10 1/4"
1' 8"	1' 7 3/4"	1' 8 1/2"	1' 7 1/2"	1' 8 3/4"	1' 7 1/4"	1' 9 1/4"
1' 7"	1' 6 3/4"	1' 7 1/2"	1' 6 1/2"	1' 7 3/4"	1' 6 1/2"	1' 8"
1' 6"	1' 5 3/4"	1' 6 1/2"	1' 5 3/4"	1' 6 3/4"	1' 5 1/2"	1' 7"
1' 5"	1' 4 3/4"	1' 5 1/2"	1' 4 3/4"	1' 5 1/2"	1' 4 1/2"	1' 5 3/4"
1' 4"	1' 3 3/4"	1' 4 1/4"	1' 3 3/4"	1' 4 1/2"	1' 3 1/2"	1' 4 3/4"
1' 3"	1' 2 3/4"	1' 3 1/4"	1' 2 3/4"	1' 3 1/2"	1' 2 3/4"	1' 3 1/2"
1' 2"	1' 2"	1' 2 1/4"	1' 1 3/4"	1' 2 1/4"	1' 1 3/4"	1' 2 1/2"
1' 1"	1' 1"	1' 1 1/4"	1' 3/4"	1' 1 1/4"	1' 3/4"	1' 1 1/4"
1'	1'	1' 1/4"	1'	1' 1/4"	1' 1 3/4"	1' 1/4"

Depth of field tables

**Compact Prime CP.2 35mm/T1.5 Super Speed T\***

circle of confusion: 0.025 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	19' 1 1/2"	INF	13' 1/4"	INF	9' 1/4"	INF
40'	13' 1"	INF	9' 11 1/2"	INF	7' 5 1/2"	INF
20'	9' 11 1/2"	INF	8' 1/2"	INF	6' 4 1/4"	INF
10'	6' 8 3/4"	31' 9"	5' 10"	177' 2 3/4"	4' 11"	INF
8'	5' 9 1/2"	17' 3 3/4"	5' 1 1/2"	30' 10 1/2"	4' 5"	INF
6'	4' 8 1/4"	9' 10 1/4"	4' 3"	13'	3' 9 1/4"	24' 3/4"
5'	4' 1"	7' 4"	3' 9"	8' 10 1/2"	3' 4 1/2"	12' 9 3/4"
4' 6"	3' 9"	6' 3"	3' 5 3/4"	7' 4"	3' 1 3/4"	9' 9 1/4"
4'	3' 4 3/4"	5' 3 1/2"	3' 2 1/4"	6' 1/4"	2' 11"	7' 6 1/4"
3' 6"	3' 1/2"	4' 5"	2' 10 1/2"	4' 10 3/4"	2' 8"	5' 9 3/4"
3'	2' 8"	3' 7 1/2"	2' 6 1/2"	3' 11"	2' 4 1/2"	4' 5 1/2"
2' 9"	2' 5 3/4"	3' 3"	2' 4 1/2"	3' 5 3/4"	2' 2 3/4"	3' 10 3/4"
2' 6"	2' 3 1/4"	2' 10 3/4"	2' 2 1/4"	3' 3/4"	2' 1"	3' 4 1/2"
2' 3"	2' 1"	2' 6 1/2"	2'	2' 8 1/4"	1' 11"	2' 10 3/4"
2'	1' 10 1/2"	2' 2 3/4"	1' 9 3/4"	2' 3 3/4"	1' 8 3/4"	2' 5 1/2"
1' 11"	1' 9 1/2"	2' 1 1/4"	1' 9"	2' 2 1/2"	1' 8 1/4"	2' 4"
1' 10"	1' 8 3/4"	2'	1' 8 1/4"	2' 1"	1' 7 1/2"	2' 2 1/2"
1' 9"	1' 7 3/4"	1' 10 3/4"	1' 7 1/4"	1' 11 3/4"	1' 6 3/4"	2' 3/4"
1' 8"	1' 7"	1' 9 3/4"	1' 6 1/2"	1' 10 1/4"	1' 6"	1' 11 1/4"
1' 7"	1' 6"	1' 8 1/2"	1' 5 3/4"	1' 9"	1' 5 1/4"	1' 10"
1' 6"	1' 5 1/4"	1' 7 1/4"	1' 4 3/4"	1' 7 3/4"	1' 4 1/2"	1' 8 1/2"
1' 5"	1' 4 1/4"	1' 6"	1' 4"	1' 6 1/2"	1' 3 1/2"	1' 7"
1' 4"	1' 3 1/2"	1' 4 3/4"	1' 3 1/4"	1' 5 1/4"	1' 2 3/4"	1' 5 3/4"
1' 3"	1' 2 1/2"	1' 3 3/4"	1' 2 1/4"	1' 4"	1' 2"	1' 4 1/2"
1' 2"	1' 1 1/2"	1' 2 1/2"	1' 1 1/2"	1' 2 3/4"	1' 1 1/4"	1' 3 1/4"
1' 1"	1' 3/4"	1' 1 1/2"	1' 1/2"	1' 1 3/4"	1' 1/4"	1' 2"
1'	11 3/4"	1' 1/4"	11 3/4"	1' 1/2"	11 1/2"	1' 3/4"



Depth of field tables

## Compact Prime CP.2 50mm/T1.5 Super Speed T\*

circle of confusion: 0.025 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	316' 10"	INF	185' 1/4"	INF	95' 10 3/4"	INF
50'	43' 2 1/2"	404' 7 1/2"	39' 5"	INF	32' 11 1/4"	INF
30'	27' 5"	62' 9 1/4"	25' 10 1/4"	105' 10 1/4"	22' 11"	468' 4"
20'	18' 10"	30' 6 1/4"	18' 3/4"	37' 11 3/4"	16' 7 1/4"	52' 4 3/4"
15'	14' 4"	20' 2"	13' 10 3/4"	23' 1 3/4"	13' 1/4"	27' 9"
12'	11' 6 3/4"	15' 3/4"	11' 3 1/2"	16' 7 3/4"	10' 8 1/2"	18' 10 1/2"
10'	9' 8 1/2"	12' 1/4"	9' 6"	13'	9' 1"	14' 3 1/2"
9'	8' 9"	10' 7"	8' 7 1/4"	11' 4"	8' 3"	12' 3 3/4"
8'	7' 9 3/4"	9' 2 3/4"	7' 8 1/4"	9' 9 1/4"	7' 5"	10' 5 3/4"
7'	6' 10 1/4"	7' 10 3/4"	6' 9"	8' 3 3/4"	6' 6 1/2"	8' 9 3/4"
6' 6"	6' 4 1/2"	7' 3 1/4"	6' 3 1/2"	7' 7 1/4"	6' 1 1/4"	8' 1/4"
6'	5' 10 3/4"	6' 7 3/4"	5' 9 3/4"	6' 11"	5' 8"	7' 3 1/4"
5' 6"	5' 5"	6' 1/4"	5' 4 1/4"	6' 3"	5' 2 3/4"	6' 6 1/4"
5'	4' 11"	5' 5 1/4"	4' 10 1/2"	5' 7 1/4"	4' 9 1/4"	5' 10"
4' 9"	4' 8 1/4"	5' 1 1/2"	4' 7 3/4"	5' 3 1/2"	4' 6 1/2"	5' 5 3/4"
4' 6"	4' 5 1/4"	4' 10"	4' 4 3/4"	4' 11 3/4"	4' 3 3/4"	5' 1 3/4"
4' 3"	4' 2 1/4"	4' 6 1/2"	4' 2"	4' 8"	4' 1"	4' 9 3/4"
4'	3' 11 1/2"	4' 3 1/4"	3' 11"	4' 4 1/2"	3' 10 1/4"	4' 6"
3' 9"	3' 8 1/2"	3' 11 3/4"	3' 8 1/4"	4' 3/4"	3' 7 1/2"	4' 2 1/4"
3' 6"	3' 5 1/2"	3' 8 1/4"	3' 5 1/4"	3' 9 1/4"	3' 4 3/4"	3' 10 1/2"
3' 3"	3' 2 3/4"	3' 5"	3' 2 1/2"	3' 5 3/4"	3' 1 3/4"	3' 6 3/4"
3'	2' 11 3/4"	3' 1 3/4"	2' 11 1/2"	3' 2 1/4"	2' 11"	3' 3"
2' 9"	2' 8 3/4"	2' 10 1/4"	2' 8 1/2"	2' 11"	2' 8 1/4"	2' 11 1/2"
2' 6"	2' 5 3/4"	2' 7"	2' 5 3/4"	2' 7 1/2"	2' 5 1/4"	2' 8"
2' 3"	2' 2 3/4"	2' 3 3/4"	2' 2 3/4"	2' 4 1/4"	2' 2 1/2"	2' 4 1/2"
2'	1' 11 3/4"	2' 3/4"	1' 11 3/4"	2' 1"	1' 11 1/2"	2' 1 1/4"
1' 11"	1' 11"	1' 11 1/2"	1' 10 3/4"	1' 11 3/4"	1' 10 3/4"	2'
1' 10"	1' 10"	1' 10 1/2"	1' 9 3/4"	1' 10 3/4"	1' 9 3/4"	1' 11"
1' 9"	1' 9"	1' 9 1/2"	1' 8 3/4"	1' 9 3/4"	1' 8 3/4"	1' 9 3/4"
1' 8"	1' 8"	1' 8 1/2"	1' 7 3/4"	1' 8 1/2"	1' 7 3/4"	1' 8 3/4"
1' 7"	1' 7"	1' 7 1/4"	1' 6 3/4"	1' 7 1/2"	1' 6 3/4"	1' 7 3/4"
1' 6"	1' 6"	1' 6 1/4"	1' 6"	1' 6 1/2"	1' 5 3/4"	1' 6 1/2"

Depth of field tables

**Compact Prime CP.2 50mm/T1.5 Super Speed T\***

circle of confusion: 0.025 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
<b>INF</b>	54' 1/4"	INF	32' 10 3/4"	INF	21' 1 3/4"	INF
<b>50'</b>	26' 3/4"	INF	19' 11 1/2"	INF	14' 11 1/2"	INF
<b>30'</b>	19' 4 1/2"	INF	15' 9 3/4"	INF	12' 6 1/4"	INF
<b>20'</b>	14' 8"	101' 9 1/2"	12' 6 1/2"	INF	10' 4 3/4"	INF
<b>15'</b>	11' 9 3/4"	37' 3"	10' 4 3/4"	69' 10"	8' 10 3/4"	INF
<b>12'</b>	9' 10 1/2"	22' 9 1/2"	8' 10 1/2"	31' 9 1/2"	7' 9 1/4"	71' 6 1/4"
<b>10'</b>	8' 6"	16' 5"	7' 9"	20' 7"	6' 10 3/4"	31' 11 3/4"
<b>9'</b>	7' 9 1/4"	13' 10"	7' 1 3/4"	16' 8"	6' 5"	23' 4 1/2"
<b>8'</b>	7' 1/4"	11' 6 3/4"	6' 6"	13' 5 1/2"	5' 10 3/4"	17' 5 3/4"
<b>7'</b>	6' 2 3/4"	9' 6 3/4"	5' 10"	10' 9 1/2"	5' 4 1/4"	13' 2 1/2"
<b>6' 6"</b>	5' 10"	8' 7 1/2"	5' 5 3/4"	9' 7 1/2"	5' 3/4"	11' 5 3/4"
<b>6'</b>	5' 5 1/4"	7' 9"	5' 1 1/2"	8' 6 1/2"	4' 9"	9' 11 1/2"
<b>5' 6"</b>	5' 1/4"	6' 11"	4' 9 1/4"	7' 6 1/2"	4' 5 1/4"	8' 7 1/4"
<b>5'</b>	4' 7 1/4"	6' 1 1/2"	4' 4 3/4"	6' 7 1/4"	4' 1 1/2"	7' 5"
<b>4' 9"</b>	4' 4 3/4"	5' 9"	4' 2 1/2"	6' 2"	3' 11 1/2"	6' 10 1/4"
<b>4' 6"</b>	4' 2 1/4"	5' 4 1/2"	4'	5' 9"	3' 9 1/4"	6' 4"
<b>4' 3"</b>	3' 11 1/2"	5' 1/4"	3' 9 3/4"	5' 4"	3' 7 1/4"	5' 10"
<b>4'</b>	3' 9"	4' 8"	3' 7 1/4"	4' 11 1/4"	3' 5"	5' 4 1/4"
<b>3' 9"</b>	3' 6 1/2"	4' 4"	3' 5"	4' 6 1/2"	3' 3"	4' 10 3/4"
<b>3' 6"</b>	3' 3 3/4"	4'	3' 2 1/2"	4' 2"	3' 3/4"	4' 5 1/2"
<b>3' 3"</b>	3' 1"	3' 8"	3'	3' 9 3/4"	2' 10 1/2"	4' 3/4"
<b>3'</b>	2' 10 1/4"	3' 4"	2' 9 1/2"	3' 5 1/2"	2' 8 1/4"	3' 8"
<b>2' 9"</b>	2' 7 3/4"	3' 1/4"	2' 6 3/4"	3' 1 1/2"	2' 5 3/4"	3' 3 1/2"
<b>2' 6"</b>	2' 5"	2' 8 3/4"	2' 4 1/4"	2' 9 1/2"	2' 3 1/4"	2' 11"
<b>2' 3"</b>	2' 2"	2' 5"	2' 1 1/2"	2' 5 3/4"	2' 1"	2' 7"
<b>2'</b>	1' 11 1/4"	2' 1 1/2"	1' 11"	2' 2"	1' 10 1/4"	2' 3"
<b>1' 11"</b>	1' 10 1/2"	2' 1/2"	1' 10"	2' 1"	1' 9 1/2"	2' 1 1/2"
<b>1' 10"</b>	1' 9 1/2"	1' 11 1/4"	1' 9"	1' 11 3/4"	1' 8 3/4"	2' 1/4"
<b>1' 9"</b>	1' 8 1/2"	1' 10"	1' 8 1/4"	1' 10 1/2"	1' 7 3/4"	1' 11"
<b>1' 8"</b>	1' 7 1/2"	1' 9"	1' 7 1/4"	1' 9 1/4"	1' 7"	1' 9 3/4"
<b>1' 7"</b>	1' 6 1/2"	1' 7 3/4"	1' 6 1/4"	1' 8 1/4"	1' 6"	1' 8 1/2"
<b>1' 6"</b>	1' 5 3/4"	1' 6 3/4"	1' 5 1/2"	1' 7"	1' 5 1/4"	1' 7 1/2"



Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.025 mm

Engraving	T-Stop					
	1.5		2		2.8	
feet	from	to	from	to	from	to
<b>INF</b>	693' 10 1/2"	INF	330' 9"	INF	298' 3 1/2"	INF
<b>200'</b>	155' 4 1/4"	280' 10"	124' 9 3/4"	242' 7 3/4"	119' 10 3/4"	360' 7 3/4"
<b>100'</b>	87' 5 1/2"	116' 9 1/4"	76' 11"	109' 7 1/2"	75' 1/4"	128' 6 3/4"
<b>60'</b>	55' 3 1/4"	65' 7 3/4"	50' 10 1/2"	63' 4"	50' 1/2"	69' 2 1/4"
<b>40'</b>	37' 10 1/4"	42' 5"	35' 9"	41' 5 1/2"	35' 4"	43' 10 1/2"
<b>30'</b>	28' 9 1/4"	31' 4"	27' 6 3/4"	30' 9 3/4"	27' 3 3/4"	32' 1 1/4"
<b>25'</b>	24' 1 3/4"	25' 11"	23' 3 1/2"	25' 6 3/4"	23' 1 1/2"	26' 5 1/4"
<b>20'</b>	19' 5 1/2"	20' 7"	18' 10 3/4"	20' 4 1/4"	18' 9 1/2"	20' 11"
<b>17'</b>	16' 7 1/4"	17' 5"	16' 2 1/2"	17' 3"	16' 1 1/2"	17' 7 3/4"
<b>15'</b>	14' 8 1/4"	15' 3 3/4"	14' 4 1/2"	15' 2 1/2"	14' 3 3/4"	15' 6"
<b>14'</b>	13' 8 3/4"	14' 3 1/4"	13' 5 1/2"	14' 2"	13' 4 3/4"	14' 5 1/4"
<b>13'</b>	12' 9 1/4"	13' 2 3/4"	12' 6 1/2"	13' 1 3/4"	12' 5 3/4"	13' 4 1/2"
<b>12'</b>	11' 9 3/4"	12' 2 1/2"	11' 7 1/4"	12' 1 1/2"	11' 6 3/4"	12' 3 3/4"
<b>11'</b>	10' 10"	11' 2"	10' 8"	11' 1 1/4"	10' 7 1/2"	11' 3 1/4"
<b>10'</b>	9' 10 1/2"	10' 1 3/4"	9' 8 3/4"	10' 1"	9' 8 1/4"	10' 2 1/2"
<b>9' 6"</b>	9' 4 1/2"	9' 7 1/2"	9' 3"	9' 7"	9' 2 3/4"	9' 8 1/4"
<b>9'</b>	8' 10 3/4"	9' 1 1/4"	8' 9 1/4"	9' 3/4"	8' 9"	9' 2"
<b>8' 6"</b>	8' 4 3/4"	8' 7 1/4"	8' 3 3/4"	8' 6 3/4"	8' 3 1/2"	8' 7 3/4"
<b>8'</b>	7' 11"	8' 1"	7' 10"	8' 3/4"	7' 9 3/4"	8' 1 3/4"
<b>7' 9"</b>	7' 8"	7' 10"	7' 7"	7' 9 1/2"	7' 6 3/4"	7' 10 1/2"
<b>7' 6"</b>	7' 5"	7' 7"	7' 4 1/4"	7' 6 1/2"	7' 4"	7' 7 1/2"
<b>7' 3"</b>	7' 2 1/4"	7' 3 3/4"	7' 1 1/4"	7' 3 1/2"	7' 1 1/4"	7' 4 1/4"
<b>7'</b>	6' 11 1/4"	7' 3/4"	6' 10 1/2"	7' 1/2"	6' 10 1/4"	7' 1 1/4"
<b>6' 9"</b>	6' 8 1/4"	6' 9 3/4"	6' 7 1/2"	6' 9 1/2"	6' 7 1/2"	6' 10 1/4"
<b>6' 6"</b>	6' 5 1/4"	6' 6 3/4"	6' 4 3/4"	6' 6 1/2"	6' 4 1/2"	6' 7"
<b>6' 3"</b>	6' 2 1/2"	6' 3 3/4"	6' 1 3/4"	6' 3 1/2"	6' 1 3/4"	6' 4"
<b>6'</b>	5' 11 1/2"	6' 1/2"	5' 11"	6' 1/4"	5' 10 3/4"	6' 1"
<b>5' 9"</b>	5' 8 1/2"	5' 9 1/2"	5' 8"	5' 9 1/4"	5' 7 3/4"	5' 9 3/4"
<b>5' 6"</b>	5' 5 1/2"	5' 6 1/2"	5' 5"	5' 6 1/4"	5' 5"	5' 6 3/4"
<b>5' 3"</b>	5' 2 1/2"	5' 3 1/2"	5' 2 1/4"	5' 3 1/4"	5' 2"	5' 3 3/4"
<b>5'</b>	4' 11 1/2"	5' 1/2"	4' 11 1/4"	5' 1/4"	4' 11 1/4"	5' 1/2"
<b>4' 9"</b>	4' 8 3/4"	4' 9 1/4"	4' 8 1/4"	4' 9 1/4"	4' 8 1/4"	4' 9 1/2"
<b>4' 6"</b>	4' 5 3/4"	4' 6 1/4"	4' 5 1/2"	4' 6 1/4"	4' 5 1/4"	4' 6 1/2"
<b>4' 3"</b>	4' 2 3/4"	4' 3 1/4"	4' 2 1/2"	4' 3 1/4"	4' 2 1/2"	4' 3 1/2"
<b>4'</b>	3' 11 3/4"	4' 1/4"	3' 11 1/2"	4' 1/4"	3' 11 1/2"	4' 1/4"
<b>3' 9"</b>	3' 8 3/4"	3' 9 1/4"	3' 8 1/2"	3' 9 1/4"	3' 8 1/2"	3' 9 1/4"
<b>3' 6"</b>	3' 5 3/4"	3' 6 1/4"	3' 5 3/4"	3' 6"	3' 5 1/2"	3' 6 1/4"
<b>3' 3"</b>	3' 2 3/4"	3' 3 1/4"	3' 2 3/4"	3' 3"	3' 2 3/4"	3' 3 1/4"

Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.025 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
<b>INF</b>	254' 6 3/4"	INF	193' 3 1/2"	INF	137' 3 1/4"	INF
<b>200'</b>	112' 1 3/4"	1009' 2"	98' 5 1/4"	INF	81' 6 1/2"	INF
<b>100'</b>	71' 11"	166' 6 3/4"	66' 1/2"	254' 3 1/2"	58'	734' 7 1/4"
<b>60'</b>	48' 7 3/4"	78' 9 3/4"	45' 10 3/4"	94' 1 1/4"	41' 10 1/2"	123' 11 3/4"
<b>40'</b>	34' 7 3/4"	47' 6 1/4"	33' 2 3/4"	52' 7 3/4"	31' 1"	60' 9 3/4"
<b>30'</b>	26' 10 3/4"	34' 1/4"	26' 1/2"	36' 6 1/2"	24' 8 1/2"	40' 3 1/4"
<b>25'</b>	22' 9 3/4"	27' 8 1/2"	22' 2 1/4"	29' 4 1/2"	21' 2 3/4"	31' 8 1/2"
<b>20'</b>	18' 7"	21' 8 1/4"	18' 2"	22' 8 1/4"	17' 6 1/4"	24' 1/2"
<b>17'</b>	15' 11 3/4"	18' 2 1/2"	15' 8"	18' 10 3/4"	15' 2 1/4"	19' 9 3/4"
<b>15'</b>	14' 2 1/2"	15' 11"	13' 11 1/2"	16' 5 1/4"	13' 7"	17' 1 3/4"
<b>14'</b>	13' 3 1/2"	14' 9 1/2"	13' 1"	15' 3"	12' 9"	15' 10"
<b>13'</b>	12' 4 3/4"	13' 8 1/4"	12' 2 1/2"	14' 3/4"	11' 11"	14' 6 3/4"
<b>12'</b>	11' 5 3/4"	12' 7"	11' 4"	12' 10 3/4"	11' 1"	13' 3 3/4"
<b>11'</b>	10' 6 3/4"	11' 5 3/4"	10' 5 1/4"	11' 9"	10' 2 3/4"	12' 1"
<b>10'</b>	9' 7 3/4"	10' 4 3/4"	9' 6 1/2"	10' 7 1/4"	9' 4 1/4"	10' 10 1/2"
<b>9' 6"</b>	9' 2 1/4"	9' 10 1/4"	9' 1"	10' 1/2"	8' 11"	10' 3 1/2"
<b>9'</b>	8' 8 1/2"	9' 3 3/4"	8' 7 1/2"	9' 5 3/4"	8' 5 3/4"	9' 8 1/2"
<b>8' 6"</b>	8' 3"	8' 9 1/4"	8' 2"	8' 11 1/4"	8' 1/2"	9' 1 1/2"
<b>8'</b>	7' 9 1/4"	8' 3"	7' 8 1/2"	8' 4 1/2"	7' 7"	8' 6 1/2"
<b>7' 9"</b>	7' 6 1/2"	7' 11 3/4"	7' 5 3/4"	8' 1 1/4"	7' 4 1/2"	8' 3"
<b>7' 6"</b>	7' 3 3/4"	7' 8 1/2"	7' 3"	7' 10"	7' 1 3/4"	7' 11 3/4"
<b>7' 3"</b>	7' 3/4"	7' 5 1/2"	7'	7' 6 3/4"	6' 11"	7' 8 1/4"
<b>7'</b>	6' 10"	7' 2 1/4"	6' 9 1/4"	7' 3 1/2"	6' 8 1/4"	7' 5"
<b>6' 9"</b>	6' 7"	6' 11"	6' 6 1/2"	7' 1/4"	6' 5 1/2"	7' 1 1/2"
<b>6' 6"</b>	6' 4 1/4"	6' 8"	6' 3 3/4"	6' 9"	6' 2 3/4"	6' 10 1/4"
<b>6' 3"</b>	6' 1 1/2"	6' 4 3/4"	6' 3/4"	6' 5 3/4"	6'	6' 6 3/4"
<b>6'</b>	5' 10 1/2"	6' 1 1/2"	5' 10"	6' 2 1/2"	5' 9 1/4"	6' 3 1/2"
<b>5' 9"</b>	5' 7 3/4"	5' 10 1/2"	5' 7 1/4"	5' 11 1/4"	5' 6 1/2"	6' 1/4"
<b>5' 6"</b>	5' 4 3/4"	5' 7 1/4"	5' 4 1/4"	5' 8"	5' 3 3/4"	5' 9"
<b>5' 3"</b>	5' 2"	5' 4 1/4"	5' 1 1/2"	5' 4 3/4"	5' 1"	5' 5 1/2"
<b>5'</b>	4' 11"	5' 1"	4' 10 3/4"	5' 1 3/4"	4' 10 1/4"	5' 2 1/4"
<b>4' 9"</b>	4' 8"	4' 10"	4' 7 3/4"	4' 10 1/2"	4' 7 1/4"	4' 11"
<b>4' 6"</b>	4' 5 1/4"	4' 6 3/4"	4' 5"	4' 7 1/4"	4' 4 1/2"	4' 7 3/4"
<b>4' 3"</b>	4' 2 1/4"	4' 3 3/4"	4' 2"	4' 4 1/4"	4' 1 3/4"	4' 4 3/4"
<b>4'</b>	3' 11 1/4"	4' 3/4"	3' 11 1/4"	4' 1"	3' 10 3/4"	4' 1 1/2"
<b>3' 9"</b>	3' 8 1/2"	3' 9 1/2"	3' 8 1/4"	3' 9 3/4"	3' 8"	3' 10 1/4"
<b>3' 6"</b>	3' 5 1/2"	3' 6 1/2"	3' 5 1/2"	3' 6 3/4"	3' 5 1/4"	3' 7"
<b>3' 3"</b>	3' 2 1/2"	3' 3 1/2"	3' 2 1/2"	3' 3 1/2"	3' 2 1/4"	3' 4"

Depth of field tables

## Compact Prime CP.2 85mm/T1.5 Super Speed T\*

circle of confusion: 0.025 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	95' 6 1/4"	INF	66' 4 1/2"	INF	46' 4"	INF
200'	64' 9 1/4"	INF	49' 11 1/2"	INF	37' 8 1/2"	INF
100'	49'	INF	40' 1/2"	INF	31' 9 1/2"	INF
60'	37'	215' 1 1/2"	31' 8"	INF	26' 3 1/2"	INF
40'	28' 3 3/4"	76' 7 3/4"	25' 1 1/4"	119' 11 3/4"	21' 7 1/2"	591' 2 1/2"
30'	22' 11 1/4"	46' 7 1/2"	20' 9 1/2"	59' 8"	18' 4 1/4"	98' 6 1/4"
25'	19' 11"	35' 6"	18' 3 1/2"	42' 6 3/4"	16' 4 1/2"	59' 1 1/4"
20'	16' 7 1/2"	26' 1 3/4"	15' 5 3/4"	29' 9"	14' 1 1/4"	36' 11 1/4"
17'	14' 6"	21' 2 1/2"	13' 7 1/2"	23' 6 1/4"	12' 6 3/4"	27' 9"
15'	13' 1/2"	18' 2"	12' 4"	19' 9 3/4"	11' 5 1/4"	22' 8 3/4"
14'	12' 3 1/4"	16' 8 1/2"	11' 7 3/4"	18' 1"	10' 10 1/4"	20' 5 3/4"
13'	11' 6"	15' 3 1/2"	10' 11 1/2"	16' 5 1/4"	10' 3"	18' 4 1/2"
12'	10' 8 3/4"	13' 11"	10' 3"	14' 10 1/4"	9' 7 1/2"	16' 5"
11'	9' 11"	12' 7"	9' 6 1/4"	13' 4"	8' 11 3/4"	14' 7"
10'	9' 1 1/4"	11' 3 1/4"	8' 9 1/4"	11' 10 1/2"	8' 3 3/4"	12' 10 1/4"
9' 6"	8' 8 1/4"	10' 7 3/4"	8' 4 1/2"	11' 2"	7' 11 3/4"	12' 1/4"
9'	8' 3 1/4"	10' 1/4"	8'	10' 5 3/4"	7' 7 1/2"	11' 2 3/4"
8' 6"	7' 10 1/4"	9' 4 3/4"	7' 7 1/4"	9' 9 3/4"	7' 3 1/4"	10' 5 1/4"
8'	7' 5"	8' 9 1/2"	7' 2 1/2"	9' 1 3/4"	6' 10 3/4"	9' 8 1/4"
7' 9"	7' 2 1/2"	8' 5 3/4"	7'	8' 9 3/4"	6' 8 1/2"	9' 3 3/4"
7' 6"	7'	8' 2 1/4"	6' 9 1/2"	8' 5 3/4"	6' 6 1/4"	8' 11 1/2"
7' 3"	6' 9 1/4"	7' 10 1/2"	6' 7"	8' 2"	6' 4"	8' 7 1/4"
7'	6' 6 3/4"	7' 7"	6' 4 3/4"	7' 10"	6' 1 3/4"	8' 3"
6' 9"	6' 4"	7' 3 1/2"	6' 2 1/4"	7' 6 1/4"	5' 11 1/2"	7' 10 3/4"
6' 6"	6' 1 1/2"	7'	5' 11 3/4"	7' 2 1/2"	5' 9 1/4"	7' 6 1/2"
6' 3"	5' 10 3/4"	6' 8 1/2"	5' 9 1/4"	6' 10 3/4"	5' 7"	7' 2 1/2"
6'	5' 8 1/4"	6' 5"	5' 6 1/2"	6' 7 1/4"	5' 4 1/2"	6' 10 1/2"
5' 9"	5' 5 1/2"	6' 1 1/2"	5' 4"	6' 3 1/2"	5' 2 1/4"	6' 6 1/2"
5' 6"	5' 2 3/4"	5' 10"	5' 1 1/2"	6'	4' 11 3/4"	6' 2 1/2"
5' 3"	5'	5' 6 3/4"	4' 11"	5' 8 1/4"	4' 9 1/4"	5' 10 3/4"
5'	4' 9 1/4"	5' 3 1/4"	4' 8 1/4"	5' 4 3/4"	4' 6 3/4"	5' 7"
4' 9"	4' 6 3/4"	5'	4' 5 3/4"	5' 1 1/4"	4' 4 1/4"	5' 3 1/4"
4' 6"	4' 4"	4' 8 3/4"	4' 3"	4' 9 3/4"	4' 1 3/4"	4' 11 1/2"
4' 3"	4' 1 1/4"	4' 5 1/4"	4' 1/4"	4' 6 1/4"	3' 11 1/4"	4' 7 3/4"
4'	3' 10 1/4"	4' 2"	3' 9 3/4"	4' 3"	3' 8 3/4"	4' 4 1/4"
3' 9"	3' 7 1/2"	3' 10 3/4"	3' 7"	3' 11 1/2"	3' 6 1/4"	4' 1/2"
3' 6"	3' 4 3/4"	3' 7 1/2"	3' 4 1/4"	3' 8"	3' 3 1/2"	3' 9"
3' 3"	3' 2"	3' 4 1/4"	3' 1 1/2"	3' 4 3/4"	3' 1"	3' 5 1/2"

Depth of field tables

## Compact Prime CP.2 35mm/T1.5 Super Speed T\*

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.5		2		2.8	
feet	from	to	from	to	from	to
INF	105' 8 1/4"	INF	90' 1 1/4"	INF	69' 1 3/4"	INF
40'	29' 1 3/4"	64' 10 1/2"	27' 10 1/4"	97' 3/4"	25' 6"	387' 8 1/2"
20'	16' 10 3/4"	24' 7 3/4"	16' 5 1/2"	28' 1 1/2"	15' 7 1/2"	35' 9"
10'	9' 2 1/4"	11'	9' 3/4"	11' 7 1/2"	8' 9 3/4"	12' 8 1/4"
8'	7' 5 3/4"	8' 7 1/2"	7' 4 3/4"	8' 11 3/4"	7' 2 3/4"	9' 7 1/4"
6'	5' 8 1/2"	6' 4"	5' 8"	6' 6 1/4"	5' 6 3/4"	6' 10"
5'	4' 9 1/2"	5' 2 3/4"	4' 9 1/4"	5' 4 1/4"	4' 8 1/2"	5' 6 1/2"
4' 6"	4' 4"	4' 8"	4' 3 3/4"	4' 9 1/4"	4' 3 1/4"	4' 11 1/4"
4'	3' 10 1/2"	4' 1 3/4"	3' 10 1/4"	4' 2 1/2"	3' 9 3/4"	4' 4"
3' 6"	3' 5"	3' 7 1/4"	3' 4 3/4"	3' 7 3/4"	3' 4 1/4"	3' 9"
3'	2' 11 1/4"	3' 3/4"	2' 11"	3' 1 1/4"	2' 10 3/4"	3' 2"
2' 9"	2' 8 1/4"	2' 9 3/4"	2' 8 1/4"	2' 10"	2' 8"	2' 10 3/4"
2' 6"	2' 5 1/2"	2' 6 1/2"	2' 5 1/2"	2' 6 3/4"	2' 5 1/4"	2' 7 1/4"
2' 3"	2' 2 1/2"	2' 3 1/2"	2' 2 1/2"	2' 3 3/4"	2' 2 1/2"	2' 4"
2'	1' 11 3/4"	2' 1/4"	1' 11 3/4"	2' 1/2"	1' 11 1/2"	2' 3/4"
1' 11"	1' 10 3/4"	1' 11 1/4"	1' 10 3/4"	1' 11 1/2"	1' 10 1/2"	1' 11 3/4"
1' 10"	1' 9 3/4"	1' 10 1/4"	1' 9 3/4"	1' 10 1/2"	1' 9 1/2"	1' 10 1/2"
1' 9"	1' 8 3/4"	1' 9 1/4"	1' 8 3/4"	1' 9 1/4"	1' 8 3/4"	1' 9 1/2"
1' 8"	1' 7 3/4"	1' 8 1/4"	1' 7 3/4"	1' 8 1/4"	1' 7 3/4"	1' 8 1/2"
1' 7"	1' 6 3/4"	1' 7 1/4"	1' 6 3/4"	1' 7 1/4"	1' 6 3/4"	1' 7 1/2"
1' 6"	1' 5 3/4"	1' 6 1/4"	1' 5 3/4"	1' 6 1/4"	1' 5 3/4"	1' 6 1/4"
1' 5"	1' 4 3/4"	1' 5 1/4"	1' 4 3/4"	1' 5 1/4"	1' 4 3/4"	1' 5 1/4"
1' 4"	1' 4"	1' 4"	1' 3 3/4"	1' 4 1/4"	1' 3 3/4"	1' 4 1/4"
1' 3"	1' 3"	1' 3"	1' 3"	1' 3 1/4"	1' 2 3/4"	1' 3 1/4"
1' 2"	1' 2"	1' 2"	1' 2"	1' 2"	1' 2"	1' 2 1/4"
1' 1"	1' 1"	1' 1"	1' 1"	1' 1"	1' 1"	1' 1 1/4"
1'	1'	1'	1'	1'	1'	1'

Depth of field tables

## Compact Prime CP.2 35mm/T1.5 Super Speed T\*

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	50' 3/4"	INF	34' 2 1/4"	INF	22' 11 3/4"	INF
40'	22' 4 3/4"	INF	18' 7 1/4"	INF	14' 9"	INF
20'	14' 5 1/4"	55' 4"	12' 9 1/4"	180' 8 1/2"	10' 10 1/4"	INF
10'	8' 5 1/4"	14' 5 1/4"	7' 10 1/4"	17' 6"	7' 1 1/4"	24' 3 1/4"
8'	6' 11 3/4"	10' 6 1/2"	6' 7"	12' 3/4"	6' 3/4"	14' 10 1/4"
6'	5' 5"	7' 3 1/4"	5' 2 1/4"	7' 11 1/4"	4' 10 1/2"	9' 1/4"
5'	4' 7 1/4"	5' 10"	4' 5 1/4"	6' 2 3/4"	4' 2 1/2"	6' 10 1/2"
4' 6"	4' 2 1/4"	5' 1 3/4"	4' 1/2"	5' 5 1/2"	3' 10 1/4"	5' 11 1/4"
4'	3' 9"	4' 6"	3' 7 3/4"	4' 8 3/4"	3' 6"	5' 3/4"
3' 6"	3' 3 3/4"	3' 10 1/4"	3' 2 3/4"	4' 1/4"	3' 1 1/4"	4' 3"
3'	2' 10 1/2"	3' 3"	2' 9 3/4"	3' 4 1/4"	2' 8 3/4"	3' 6 1/4"
2' 9"	2' 7 3/4"	2' 11 1/2"	2' 7"	3' 1/2"	2' 6 1/4"	3' 2"
2' 6"	2' 5"	2' 8"	2' 4 1/2"	2' 8 3/4"	2' 3 3/4"	2' 10"
2' 3"	2' 2 1/4"	2' 4 1/2"	2' 1 3/4"	2' 5 1/4"	2' 1 1/4"	2' 6"
2'	1' 11 1/4"	2' 1"	1' 11"	2' 1 1/2"	1' 10 3/4"	2' 2 1/4"
1' 11"	1' 10 1/2"	2'	1' 10 1/4"	2' 1/2"	1' 9 3/4"	2' 1"
1' 10"	1' 9 1/2"	1' 11"	1' 9 1/4"	1' 11 1/4"	1' 9"	1' 11 3/4"
1' 9"	1' 8 1/2"	1' 9 3/4"	1' 8 1/4"	1' 10"	1' 8"	1' 10 1/2"
1' 8"	1' 7 1/2"	1' 8 3/4"	1' 7 1/2"	1' 9"	1' 7 1/4"	1' 9 1/2"
1' 7"	1' 6 3/4"	1' 7 1/2"	1' 6 1/2"	1' 7 3/4"	1' 6 1/4"	1' 8 1/4"
1' 6"	1' 5 3/4"	1' 6 1/2"	1' 5 1/2"	1' 6 3/4"	1' 5 1/4"	1' 7"
1' 5"	1' 4 3/4"	1' 5 1/2"	1' 4 1/2"	1' 5 3/4"	1' 4 1/2"	1' 6"
1' 4"	1' 3 3/4"	1' 4 1/2"	1' 3 3/4"	1' 4 1/2"	1' 3 1/2"	1' 4 3/4"
1' 3"	1' 2 3/4"	1' 3 1/4"	1' 2 3/4"	1' 3 1/2"	1' 2 1/2"	1' 3 1/2"
1' 2"	1' 1 3/4"	1' 2 1/4"	1' 1 3/4"	1' 2 1/4"	1' 1 3/4"	1' 2 1/2"
1' 1"	1' 3/4"	1' 1 1/4"	1' 3/4"	1' 1 1/4"	1' 3/4"	1' 1 1/2"
1'	1'	1' 1/4"	11 3/4"	1' 1/4"	11 3/4"	1' 1/4"

Depth of field tables

**Compact Prime CP.2 35mm/T1.5 Super Speed T\***

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	15' 6 3/4"	INF	10' 8 1/2"	INF	7' 5 3/4"	INF
40'	11' 4 1/4"	INF	8' 6 3/4"	INF	6' 4 3/4"	INF
20'	8' 11"	INF	7' 1 1/2"	INF	5' 7"	INF
10'	6' 3"	52' 2 1/2"	5' 4 1/4"	INF	4' 5 1/2"	INF
8'	5' 5 1/4"	21' 10 3/4"	4' 9"	67' 3 1/4"	4' 1/2"	INF
6'	4' 5 3/4"	11' 1 3/4"	4'	16' 8"	3' 6"	59' 6"
5'	3' 11"	8'	3' 6 3/4"	10' 5"	3' 2"	18' 6 1/4"
4' 6"	3' 7 1/4"	6' 8 3/4"	3' 3 3/4"	8' 4"	2' 11 3/4"	12' 8 1/2"
4'	3' 3 1/2"	5' 7 1/2"	3' 1/2"	6' 8"	2' 9 1/4"	9' 1 1/2"
3' 6"	2' 11 1/2"	4' 7 3/4"	2' 9 1/4"	5' 3 3/4"	2' 6 1/2"	6' 8 1/4"
3'	2' 7 1/4"	3' 9"	2' 5 1/2"	4' 2"	2' 3 1/2"	4' 11 1/4"
2' 9"	2' 5"	3' 4 1/4"	2' 3 1/2"	3' 8"	2' 1 3/4"	4' 3"
2' 6"	2' 2 3/4"	2' 11 3/4"	2' 1 1/2"	3' 2 1/2"	2'	3' 7 1/2"
2' 3"	2' 1/2"	2' 7 1/4"	1' 11 1/2"	2' 9 1/2"	1' 10 1/4"	3' 1"
2'	1' 10"	2' 3 1/4"	1' 9 1/4"	2' 4 3/4"	1' 8 1/4"	2' 7"
1' 11"	1' 9 1/4"	2' 1 3/4"	1' 8 1/2"	2' 3 1/4"	1' 7 3/4"	2' 5 1/4"
1' 10"	1' 8 1/2"	2' 1/2"	1' 7 3/4"	2' 1 3/4"	1' 7"	2' 3 1/2"
1' 9"	1' 7 1/2"	1' 11 1/4"	1' 7"	2' 1/4"	1' 6 1/4"	2' 1 3/4"
1' 8"	1' 6 3/4"	1' 10"	1' 6 1/4"	1' 10 3/4"	1' 5 1/2"	2' 1/4"
1' 7"	1' 6"	1' 8 3/4"	1' 5 1/2"	1' 9 1/2"	1' 4 3/4"	1' 10 1/2"
1' 6"	1' 5"	1' 7 1/2"	1' 4 3/4"	1' 8"	1' 4"	1' 9"
1' 5"	1' 4 1/4"	1' 6 1/4"	1' 3 3/4"	1' 6 3/4"	1' 3 1/4"	1' 7 1/2"
1' 4"	1' 3 1/4"	1' 5"	1' 3"	1' 5 1/2"	1' 2 1/2"	1' 6 1/4"
1' 3"	1' 2 1/2"	1' 3 3/4"	1' 2 1/4"	1' 4 1/4"	1' 1 3/4"	1' 4 3/4"
1' 2"	1' 1 1/2"	1' 2 3/4"	1' 1 1/4"	1' 3"	1' 1"	1' 3 1/2"
1' 1"	1' 1/2"	1' 1 1/2"	1' 1/2"	1' 1 3/4"	1' 1/4"	1' 2 1/4"
1'	11 3/4"	1' 1/2"	11 1/2"	1' 1/2"	11 1/4"	1' 3/4"



Depth of field tables

**Compact Prime CP.2 50mm/T1.5 Super Speed T\***

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
INF	191' 2 3/4"	INF	119' 9 1/2"	INF	68' 6 3/4"	INF
50'	39' 8 1/4"	2567' 3 3/4"	35' 4 1/4"	INF	29'	INF
30'	25' 11 1/2"	72' 1 1/2"	24' 1/2"	154' 1/2"	20' 11 1/2"	INF
20'	18' 1 1/2"	32' 6 3/4"	17' 2 1/4"	42' 8 3/4"	15' 6 3/4"	67' 1"
15'	13' 11 1/4"	21' 1/4"	13' 4 1/2"	24' 9 3/4"	12' 4 1/2"	31' 4 1/4"
12'	11' 3 3/4"	15' 6 1/4"	10' 11 1/4"	17' 5 3/4"	10' 3 1/4"	20' 5 1/2"
10'	9' 6 1/4"	12' 3 3/4"	9' 3"	13' 6"	8' 9 1/4"	15' 2 1/4"
9'	8' 7 1/4"	10' 9 3/4"	8' 4 3/4"	11' 8 1/2"	8'	12' 11 1/2"
8'	7' 8 1/4"	9' 4 3/4"	7' 6 1/4"	10' 1/2"	7' 2 1/2"	10' 11 1/2"
7'	6' 9 1/4"	8' 1/4"	6' 7 1/2"	8' 6"	6' 4 1/2"	9' 1 1/2"
6' 6"	6' 3 1/2"	7' 4 1/2"	6' 2 1/4"	7' 9 1/4"	5' 11 1/2"	8' 3 1/2"
6'	5' 10"	6' 8 3/4"	5' 8 3/4"	7' 3/4"	5' 6 1/2"	7' 5 3/4"
5' 6"	5' 4 1/4"	6' 1 1/4"	5' 3 1/4"	6' 4 1/4"	5' 1 1/2"	6' 8 1/2"
5'	4' 10 1/2"	5' 5 3/4"	4' 9 3/4"	5' 8 1/4"	4' 8 1/4"	5' 11 1/2"
4' 9"	4' 7 3/4"	5' 2 1/4"	4' 7"	5' 4 1/2"	4' 5 1/2"	5' 7 1/4"
4' 6"	4' 4 3/4"	4' 10 1/2"	4' 4 1/4"	5' 1/2"	4' 3"	5' 3"
4' 3"	4' 2"	4' 7"	4' 1 1/2"	4' 8 3/4"	4' 1/4"	4' 11"
4'	3' 11"	4' 3 1/2"	3' 10 1/2"	4' 5"	3' 9 1/2"	4' 7"
3' 9"	3' 8 1/4"	4'	3' 7 3/4"	4' 1 1/4"	3' 7"	4' 3"
3' 6"	3' 5 1/4"	3' 8 3/4"	3' 5"	3' 9 3/4"	3' 4 1/4"	3' 11"
3' 3"	3' 2 1/2"	3' 5 1/4"	3' 2"	3' 6 1/4"	3' 1 1/2"	3' 7 1/4"
3'	2' 11 1/2"	3' 1 3/4"	2' 11 1/4"	3' 2 1/2"	2' 10 3/4"	3' 3 1/2"
2' 9"	2' 8 1/2"	2' 10 1/2"	2' 8 1/4"	2' 11 1/4"	2' 8"	3'
2' 6"	2' 5 3/4"	2' 7 1/4"	2' 5 1/2"	2' 7 3/4"	2' 5"	2' 8 1/4"
2' 3"	2' 2 3/4"	2' 4"	2' 2 1/2"	2' 4 1/4"	2' 2 1/4"	2' 4 3/4"
2'	1' 11 3/4"	2' 3/4"	1' 11 3/4"	2' 1"	1' 11 1/2"	2' 1 1/4"
1' 11"	1' 10 3/4"	1' 11 3/4"	1' 10 3/4"	2'	1' 10 1/2"	2' 1/4"
1' 10"	1' 9 3/4"	1' 10 1/2"	1' 9 3/4"	1' 10 3/4"	1' 9 1/2"	1' 11"
1' 9"	1' 8 3/4"	1' 9 1/2"	1' 8 3/4"	1' 9 3/4"	1' 8 1/2"	1' 10"
1' 8"	1' 7 3/4"	1' 8 1/2"	1' 7 3/4"	1' 8 3/4"	1' 7 3/4"	1' 8 3/4"
1' 7"	1' 7"	1' 7 1/2"	1' 6 3/4"	1' 7 1/2"	1' 6 3/4"	1' 7 3/4"
1' 6"	1' 6"	1' 6 1/4"	1' 5 3/4"	1' 6 1/2"	1' 5 3/4"	1' 6 3/4"



Depth of field tables

**Compact Prime CP.2 50mm/T1.5 Super Speed T\***

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	41' 1/2"	INF	25' 10 3/4"	INF	17' 1/4"	INF
50'	22' 7 3/4"	INF	17' 2"	INF	12' 9 1/4"	INF
30'	17' 5 1/4"	INF	14' 1/4"	INF	10' 11 1/2"	INF
20'	13' 6 1/2"	258' 3/4"	11' 4 3/4"	INF	9' 3 3/4"	INF
15'	11' 3/4"	47' 8 3/4"	9' 7 1/4"	169' 6 3/4"	8' 1"	INF
12'	9' 4 1/4"	26' 3 1/2"	8' 3 1/2"	43' 3 1/2"	7' 1 3/4"	493' 4 1/4"
10'	8' 1 1/4"	18' 1 3/4"	7' 3 3/4"	24' 9 3/4"	6' 5"	51' 6 1/4"
9'	7' 5 1/4"	15' 1/2"	6' 9 1/4"	19' 3 3/4"	6'	32' 3"
8'	6' 9"	12' 4 3/4"	6' 2 1/4"	15' 1 1/2"	5' 6 1/2"	21' 11 3/4"
7'	6' 1/2"	10' 1 1/4"	5' 7"	11' 10"	5' 3/4"	15' 7 1/4"
6' 6"	5' 8"	9' 3/4"	5' 3 1/4"	10' 5 1/4"	4' 9 1/2"	13' 2 3/4"
6'	5' 3 1/2"	8' 1 1/4"	4' 11 1/4"	9' 2"	4' 6 1/4"	11' 3"
5' 6"	4' 10 3/4"	7' 2 1/2"	4' 7 1/4"	8' 1/4"	4' 3"	9' 6 1/2"
5'	4' 6"	6' 4 1/4"	4' 3"	6' 11 1/2"	3' 11 1/4"	8' 1"
4' 9"	4' 3 1/2"	5' 11 1/4"	4' 1"	6' 5 3/4"	3' 9 1/2"	7' 5"
4' 6"	4' 1 1/4"	5' 6 1/2"	3' 10 3/4"	6'	3' 7 3/4"	6' 9 3/4"
4' 3"	3' 10 3/4"	5' 2"	3' 8 1/2"	5' 6 3/4"	3' 5 3/4"	6' 2 3/4"
4'	3' 8 1/4"	4' 9 1/2"	3' 6 1/4"	5' 1 1/2"	3' 3 3/4"	5' 8 1/4"
3' 9"	3' 5 3/4"	4' 5 1/4"	3' 4"	4' 8 1/2"	3' 1 3/4"	5' 2"
3' 6"	3' 3"	4' 1"	3' 1 1/2"	4' 3 3/4"	2' 11 3/4"	4' 8 1/4"
3' 3"	3' 1/2"	3' 8 3/4"	2' 11 1/4"	3' 11"	2' 9 1/2"	4' 2 3/4"
3'	2' 10"	3' 4 3/4"	2' 8 3/4"	3' 6 3/4"	2' 7 1/4"	3' 9 3/4"
2' 9"	2' 7 1/4"	3' 1"	2' 6 1/4"	3' 2 1/2"	2' 5"	3' 4 3/4"
2' 6"	2' 4 1/2"	2' 9"	2' 3 3/4"	2' 10 1/4"	2' 2 3/4"	3'
2' 3"	2' 1 3/4"	2' 5 1/2"	2' 1 1/4"	2' 6 1/4"	2' 1/2"	2' 7 3/4"
2'	1' 11"	2' 1 3/4"	1' 10 3/4"	2' 2 1/2"	1' 10"	2' 3 1/2"
1' 11"	1' 10 1/4"	2' 3/4"	1' 9 3/4"	2' 1 1/4"	1' 9 1/4"	2' 2 1/4"
1' 10"	1' 9 1/4"	1' 11 1/2"	1' 9"	2'	1' 8 1/4"	2' 3/4"
1' 9"	1' 8 1/4"	1' 10 1/4"	1' 8"	1' 10 3/4"	1' 7 1/2"	1' 11 1/2"
1' 8"	1' 7 1/2"	1' 9 1/4"	1' 7"	1' 9 1/2"	1' 6 3/4"	1' 10 1/4"
1' 7"	1' 6 1/2"	1' 8"	1' 6 1/4"	1' 8 1/2"	1' 5 3/4"	1' 9"
1' 6"	1' 5 1/2"	1' 7"	1' 5 1/4"	1' 7 1/4"	1' 5"	1' 7 3/4"

Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.5		2		2.8	
feet	from	to	from	to	from	to
<b>INF</b>	578' 3 3/4"	INF	293' 1/4"	INF	255' 9 1/2"	INF
<b>200'</b>	148' 8 1/2"	305' 6 1/2"	119' 1/2"	268'	112' 5"	451' 7 1/2"
<b>100'</b>	85' 3 3/4"	120' 9 3/4"	74' 8 1/4"	114' 6"	72' 1/4"	138' 5 1/2"
<b>60'</b>	54' 4 3/4"	66' 10 3/4"	49' 11"	64' 11"	48' 8 1/2"	71' 11 1/2"
<b>40'</b>	37' 5 1/4"	42' 11 1/4"	35' 3 1/4"	42' 1 1/2"	34' 8"	44' 11 1/2"
<b>30'</b>	28' 6 1/2"	31' 7 1/2"	27' 3 1/4"	31' 2"	26' 11"	32' 8 1/4"
<b>25'</b>	23' 11 3/4"	26' 1 1/4"	23' 1"	25' 9 3/4"	22' 10"	26' 10"
<b>20'</b>	19' 4 1/4"	20' 8 1/2"	18' 9 1/4"	20' 6 1/4"	18' 7 1/4"	21' 1 3/4"
<b>17'</b>	16' 6 1/4"	17' 6"	16' 1 1/4"	17' 4 1/2"	15' 11 3/4"	17' 9 3/4"
<b>15'</b>	14' 7 1/2"	15' 4 3/4"	14' 3 3/4"	15' 3 1/2"	14' 2 1/2"	15' 7 1/2"
<b>14'</b>	13' 8 1/4"	14' 4"	13' 4 3/4"	14' 3"	13' 3 3/4"	14' 6 1/2"
<b>13'</b>	12' 8 3/4"	13' 3 1/2"	12' 5 3/4"	13' 2 1/2"	12' 4 3/4"	13' 5 1/2"
<b>12'</b>	11' 9 1/4"	12' 3"	11' 6 3/4"	12' 2 1/4"	11' 6"	12' 4 3/4"
<b>11'</b>	10' 9 3/4"	11' 2 1/2"	10' 7 1/2"	11' 1 3/4"	10' 7"	11' 4"
<b>10'</b>	9' 10"	10' 2"	9' 8 1/4"	10' 1 1/2"	9' 7 3/4"	10' 3 1/4"
<b>9' 6"</b>	9' 4 1/4"	9' 7 3/4"	9' 2 3/4"	9' 7 1/4"	9' 2 1/4"	9' 9"
<b>9'</b>	8' 10 1/2"	9' 1 1/2"	8' 9"	9' 1 1/4"	8' 8 1/2"	9' 2 1/2"
<b>8' 6"</b>	8' 4 1/2"	8' 7 1/2"	8' 3 1/4"	8' 7"	8' 3"	8' 8 1/4"
<b>8'</b>	7' 10 3/4"	8' 1 1/4"	7' 9 3/4"	8' 1"	7' 9 1/4"	8' 2"
<b>7' 9"</b>	7' 7 3/4"	7' 10 1/4"	7' 6 3/4"	7' 10"	7' 6 1/2"	7' 11"
<b>7' 6"</b>	7' 5"	7' 7"	7' 4"	7' 6 3/4"	7' 3 3/4"	7' 7 3/4"
<b>7' 3"</b>	7' 2"	7' 4"	7' 1"	7' 3 3/4"	7' 3/4"	7' 4 3/4"
<b>7'</b>	6' 11"	7' 1"	6' 10 1/4"	7' 3/4"	6' 10"	7' 1 1/2"
<b>6' 9"</b>	6' 8 1/4"	6' 10"	6' 7 1/4"	6' 9 3/4"	6' 7"	6' 10 1/2"
<b>6' 6"</b>	6' 5 1/4"	6' 6 3/4"	6' 4 1/2"	6' 6 1/2"	6' 4 1/4"	6' 7 1/4"
<b>6' 3"</b>	6' 2 1/4"	6' 3 3/4"	6' 1 1/2"	6' 3 1/2"	6' 1 1/2"	6' 4 1/4"
<b>6'</b>	5' 11 1/4"	6' 3/4"	5' 10 3/4"	6' 1/2"	5' 10 1/2"	6' 1"
<b>5' 9"</b>	5' 8 1/2"	5' 9 3/4"	5' 7 3/4"	5' 9 1/2"	5' 7 3/4"	5' 10"
<b>5' 6"</b>	5' 5 1/2"	5' 6 1/2"	5' 5"	5' 6 1/2"	5' 4 3/4"	5' 7"
<b>5' 3"</b>	5' 2 1/2"	5' 3 1/2"	5' 2"	5' 3 1/2"	5' 2"	5' 3 3/4"
<b>5'</b>	4' 11 1/2"	5' 1/2"	4' 11 1/4"	5' 1/4"	4' 11"	5' 3/4"
<b>4' 9"</b>	4' 8 1/2"	4' 9 1/2"	4' 8 1/4"	4' 9 1/4"	4' 8"	4' 9 3/4"
<b>4' 6"</b>	4' 5 3/4"	4' 6 1/2"	4' 5 1/4"	4' 6 1/4"	4' 5 1/4"	4' 6 1/2"
<b>4' 3"</b>	4' 2 3/4"	4' 3 1/4"	4' 2 1/2"	4' 3 1/4"	4' 2 1/4"	4' 3 1/2"
<b>4'</b>	3' 11 3/4"	4' 1/4"	3' 11 1/2"	4' 1/4"	3' 11 1/2"	4' 1/2"
<b>3' 9"</b>	3' 8 3/4"	3' 9 1/4"	3' 8 1/2"	3' 9 1/4"	3' 8 1/2"	3' 9 1/2"
<b>3' 6"</b>	3' 5 3/4"	3' 6 1/4"	3' 5 1/2"	3' 6 1/4"	3' 5 1/2"	3' 6 1/4"
<b>3' 3"</b>	3' 2 3/4"	3' 3 1/4"	3' 2 3/4"	3' 3 1/4"	3' 2 1/2"	3' 3 1/4"

Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
feet	from	to	from	to	from	to
<b>INF</b>	211' 10 1/2"	INF	158' 10 1/2"	INF	112' 9"	INF
<b>200'</b>	103' 1/2"	5129' 6 1/4"	88' 8 1/4"	INF	72' 3"	INF
<b>100'</b>	68' 3/4"	191' 11 1/4"	61' 6 1/4"	356' 7"	53' 1 3/4"	INF
<b>60'</b>	46' 10 1/2"	84' 3/4"	43' 8"	105' 2 3/4"	39' 3 1/2"	154' 6 1/2"
<b>40'</b>	33' 8 3/4"	49' 4 1/2"	32' 1/2"	55' 11 1/4"	29' 7 3/4"	67' 3 1/2"
<b>30'</b>	26' 4 1/4"	34' 11 1/2"	25' 3 3/4"	38' 1 1/4"	23' 9 1/2"	43' 1/4"
<b>25'</b>	22' 5"	28' 4"	21' 8"	30' 4 1/4"	20' 6 1/2"	33' 4 1/2"
<b>20'</b>	18' 4"	22' 3/4"	17' 10"	23' 3"	17' 3/4"	24' 11 3/4"
<b>17'</b>	15' 9 1/4"	18' 5 1/2"	15' 5"	19' 3 1/2"	14' 10"	20' 5 1/4"
<b>15'</b>	14' 1/2"	16' 1 1/2"	13' 9"	16' 9"	13' 3 1/2"	17' 7 1/4"
<b>14'</b>	13' 2"	14' 11 1/2"	12' 11"	15' 6"	12' 6 1/4"	16' 2 3/4"
<b>13'</b>	12' 3 1/2"	13' 10"	12' 3/4"	14' 3 1/4"	11' 8 1/2"	14' 10 3/4"
<b>12'</b>	11' 4 3/4"	12' 8 1/4"	11' 2 1/4"	13' 1"	10' 10 3/4"	13' 7"
<b>11'</b>	10' 5 3/4"	11' 7"	10' 4"	11' 10 3/4"	10' 3/4"	12' 3 3/4"
<b>10'</b>	9' 7"	10' 5 3/4"	9' 5 1/4"	10' 8 3/4"	9' 2 3/4"	11' 3/4"
<b>9' 6"</b>	9' 1 1/2"	9' 11"	9'	10' 1 3/4"	8' 9 3/4"	10' 5 1/2"
<b>9'</b>	8' 8"	9' 4 1/2"	8' 6 1/2"	9' 7"	8' 4 1/2"	9' 10 1/4"
<b>8' 6"</b>	8' 2 1/4"	8' 10"	8' 1 1/4"	9' 1/4"	7' 11 1/4"	9' 3"
<b>8'</b>	7' 8 3/4"	8' 3 1/2"	7' 7 3/4"	8' 5 1/2"	7' 6"	8' 7 3/4"
<b>7' 9"</b>	7' 6"	8' 1/4"	7' 5"	8' 2"	7' 3 1/2"	8' 4 1/4"
<b>7' 6"</b>	7' 3 1/4"	7' 9"	7' 2 1/4"	7' 10 3/4"	7' 3/4"	8' 3/4"
<b>7' 3"</b>	7' 1/4"	7' 5 3/4"	6' 11 1/2"	7' 7 1/4"	6' 10 1/4"	7' 9 1/4"
<b>7'</b>	6' 9 1/2"	7' 2 3/4"	6' 8 3/4"	7' 4"	6' 7 1/2"	7' 6"
<b>6' 9"</b>	6' 6 3/4"	6' 11 1/2"	6' 6"	7' 3/4"	6' 4 3/4"	7' 2 1/2"
<b>6' 6"</b>	6' 4"	6' 8 1/4"	6' 3 1/4"	6' 9 1/2"	6' 2 1/4"	6' 11"
<b>6' 3"</b>	6' 1"	6' 5"	6' 1/2"	6' 6 1/4"	5' 11 1/2"	6' 7 1/2"
<b>6'</b>	5' 10 1/4"	6' 2"	5' 9 3/4"	6' 3"	5' 8 3/4"	6' 4 1/4"
<b>5' 9"</b>	5' 7 1/4"	5' 10 3/4"	5' 6 3/4"	5' 11 3/4"	5' 6"	6' 3/4"
<b>5' 6"</b>	5' 4 1/2"	5' 7 1/2"	5' 4"	5' 8 1/2"	5' 3 1/4"	5' 9 1/2"
<b>5' 3"</b>	5' 1 3/4"	5' 4 1/2"	5' 1 1/4"	5' 5 1/4"	5' 1/2"	5' 6 1/4"
<b>5'</b>	4' 10 3/4"	5' 1 1/4"	4' 10 1/2"	5' 2"	4' 9 3/4"	5' 2 3/4"
<b>4' 9"</b>	4' 8"	4' 10 1/4"	4' 7 1/2"	4' 10 3/4"	4' 7"	4' 11 1/2"
<b>4' 6"</b>	4' 5"	4' 7"	4' 4 3/4"	4' 7 1/2"	4' 4 1/4"	4' 8 1/4"
<b>4' 3"</b>	4' 2 1/4"	4' 4"	4' 1 3/4"	4' 4 1/4"	4' 1 1/2"	4' 5"
<b>4'</b>	3' 11 1/4"	4' 3/4"	3' 11"	4' 1 1/4"	3' 10 1/2"	4' 1 3/4"
<b>3' 9"</b>	3' 8 1/4"	3' 9 3/4"	3' 8 1/4"	3' 10"	3' 7 3/4"	3' 10 1/2"
<b>3' 6"</b>	3' 5 1/2"	3' 6 1/2"	3' 5 1/4"	3' 7"	3' 5"	3' 7 1/4"
<b>3' 3"</b>	3' 2 1/2"	3' 3 1/2"	3' 2 1/4"	3' 3 3/4"	3' 2"	3' 4"

Depth of field tables

**Compact Prime CP.2 85mm/T1.5 Super Speed T\***

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
feet	from	to	from	to	from	to
INF	78' 8 1/2"	INF	54' 11"	INF	38' 5 1/2"	INF
200'	56' 7 1/4"	INF	43' 2 1/4"	INF	32' 4"	INF
100'	44' 2 1/4"	INF	35' 7"	INF	27' 10 3/4"	INF
60'	34' 2 1/4"	419' 9"	28' 10"	INF	23' 7"	INF
40'	26' 8"	92' 7 3/4"	23' 3 1/2"	194' 11 3/4"	19' 9 1/4"	INF
30'	21' 10"	52' 3/4"	19' 6 1/2"	73' 8 1/4"	17'	178' 4 1/4"
25'	19' 1"	38' 6 3/4"	17' 3 3/4"	49' 2 1/2"	15' 3 1/2"	80' 8 1/4"
20'	16' 1/2"	27' 9"	14' 9 1/4"	32' 10"	13' 3 1/2"	44' 3 1/2"
17'	14' 3/4"	22' 3"	13' 1"	25' 4 3/4"	11' 11"	31' 8 1/4"
15'	12' 8 1/4"	18' 11"	11' 10 3/4"	21' 1 1/2"	10' 11"	25' 3 1/2"
14'	11' 11 1/2"	17' 4 1/4"	11' 3"	19' 2"	10' 4 3/4"	22' 6 1/4"
13'	11' 2 3/4"	15' 9 3/4"	10' 7 1/4"	17' 4"	9' 10"	20'
12'	10' 5 3/4"	14' 4 1/4"	9' 11 1/4"	15' 6 3/4"	9' 3"	17' 8 1/4"
11'	9' 8 1/2"	12' 11 1/4"	9' 3"	13' 11"	8' 8"	15' 6 3/4"
10'	8' 11 1/4"	11' 6 3/4"	8' 6 1/2"	12' 4"	8' 1/2"	13' 7 1/4"
9' 6"	8' 6 1/2"	10' 10 3/4"	8' 2"	11' 6 3/4"	7' 8 1/2"	12' 8 1/4"
9'	8' 1 1/2"	10' 2 3/4"	7' 9 3/4"	10' 10"	7' 4 3/4"	11' 9 1/2"
8' 6"	7' 8 3/4"	9' 7"	7' 5 1/4"	10' 1 1/4"	7' 3/4"	10' 11 1/4"
8'	7' 3 3/4"	8' 11 1/2"	7' 1/2"	9' 4 3/4"	6' 8 1/2"	10' 1 1/4"
7' 9"	7' 1 1/4"	8' 7 1/2"	6' 10 1/4"	9' 1/2"	6' 6 1/2"	9' 8 1/2"
7' 6"	6' 10 3/4"	8' 4"	6' 8"	8' 8 1/2"	6' 4 1/4"	9' 3 3/4"
7' 3"	6' 8 1/4"	8' 1/4"	6' 5 1/2"	8' 4 1/2"	6' 2 1/4"	8' 11"
7'	6' 5 3/4"	7' 8 1/2"	6' 3 1/4"	8' 1/4"	6'	8' 6 1/2"
6' 9"	6' 3 1/4"	7' 4 3/4"	6' 3/4"	7' 8 1/2"	5' 9 3/4"	8' 2"
6' 6"	6' 1/2"	7' 1 1/4"	5' 10 1/2"	7' 4 1/2"	5' 7 3/4"	7' 9 1/2"
6' 3"	5' 10"	6' 9 1/2"	5' 8"	7' 1/2"	5' 5 1/2"	7' 5 1/4"
6'	5' 7 1/2"	6' 6"	5' 5 1/2"	6' 8 3/4"	5' 3 1/4"	7' 3/4"
5' 9"	5' 4 3/4"	6' 2 1/2"	5' 3"	6' 5"	5' 1"	6' 8 3/4"
5' 6"	5' 2 1/4"	5' 11"	5' 1/2"	6' 1 1/4"	4' 10 1/2"	6' 4 1/2"
5' 3"	4' 11 1/2"	5' 7 1/2"	4' 10"	5' 9 1/2"	4' 8 1/4"	6' 1/2"
5'	4' 8 3/4"	5' 4"	4' 7 1/2"	5' 5 3/4"	4' 6"	5' 8 1/2"
4' 9"	4' 6 1/4"	5' 1/2"	4' 5"	5' 2 1/4"	4' 3 1/2"	5' 4 1/2"
4' 6"	4' 3 1/2"	4' 9 1/4"	4' 2 1/2"	4' 10 1/2"	4' 1"	5' 1/2"
4' 3"	4' 3/4"	4' 5 3/4"	3' 11 3/4"	4' 7"	3' 10 1/2"	4' 8 3/4"
4'	3' 10"	4' 2 1/2"	3' 9 1/4"	4' 3 1/2"	3' 8 1/4"	4' 5"
3' 9"	3' 7 1/4"	3' 11"	3' 6 1/2"	4'	3' 5 3/4"	4' 1 1/4"
3' 6"	3' 4 1/2"	3' 7 3/4"	3' 4"	3' 8 1/2"	3' 3"	3' 9 3/4"
3' 3"	3' 1 3/4"	3' 4 1/2"	3' 1 1/4"	3' 5 1/4"	3' 1/2"	3' 6"